



TC1200



Reference Manual



Datalogic Automation Srl
Via Lavino, 256
40050 - Monte S. Pietro
Bologna - Italy

TC1200 Reference Manual

Ed.: 12/2010

This manual refers to software release 1.0.0 or later.

© 2008 – 2010 Datalogic Automation S.r.l. ♦ ALL RIGHTS RESERVED. ♦ Protected to the fullest extent under U.S. and international laws. Copying, or altering of this document is prohibited without express written consent from Datalogic Automation S.r.l.

Datalogic and the Datalogic logo are registered trademarks of Datalogic S.p.A. in many countries, including the U.S.A. and the E.U.

Aladdin and is a trademark of Datalogic S.p.A. All other brand and product names mentioned herein are for identification purposes only and may be trademarks or registered trademarks of their respective owners.

Datalogic shall not be liable for technical or editorial errors or omissions contained herein, nor for incidental or consequential damages resulting from the use of this material.

CONTENTS

REFERENCES	ix
Conventions	ix
Reference Documentation	ix
Services and Support	ix
Patents	ix
 SAFETY AND COMPLIANCE NOTICES.....	x
FCC Compliance	x
Power Supply.....	x
CE Compliance.....	x
Handling.....	xi
 1 INTRODUCTION	1
1.1 Configuration Methods.....	1
1.1.1 Configuration Using Datalogic Aladdin™	1
1.1.2 Configuration Using Serial Programming Strings	1
1.1.3 Configuration Using Programming Barcode Labels.....	1
1.2 BUTTON AND LED Indicators.....	2
1.3 Available Models.....	2
 2 INSTALLATION	3
2.1 TC1200 CCD Scanner.....	3
2.1.1 Mechanical Installation	3
2.1.2 Electrical Connections	4
2.2 TC1200 CCD Scan Engine.....	8
2.2.1 Mechanical Installation	8
2.2.2 Electrical Connections	9
2.3 Positioning	13
 3 SOFTWARE CONFIGURATION STRINGS.....	14
3.1 TC1200 Configuration.....	14
 4 BARCODE CONFIGURATION	31
4.1 Initial Setup	31
Restore Default.....	31
Interface Selection.....	31
4.2 Changing Default Settings	33
Global Interface Features	34
 RS232.....	35
Baud Rate.....	36
Parity.....	36
Data Bits	37
Stop Bits	37
 RS232/USB-COM.....	38
Intercharacter Delay	39
Disable Character	39
Enable Character.....	39
ACK/NAK Options.....	39
ACK Character.....	39

NAK Character.....	40
ACK/NAK Timeout.....	40
ACK/NAK Retry Count.....	40
ACK/NAK Error Handling.....	40
USB-KBD	41
Keyboard Country.....	42
Keyboard Country (continued).....	43
Keyboard Intercode Delay	43
Send Control Characters	44
USB Keyboard Speed.....	44
USB Keyboard Speed (continued).....	45
READING PARAMETERS	46
Illumination Mode.....	47
Operating Mode	47
Automatic Threshold.....	47
Phase Off Event.....	48
Timeout.....	48
Serial Start.....	48
Serial Stop	48
LED Indication	48
Label Programming Mode	49
DATA FORMAT	50
Data Transmission.....	51
Code Verifier Mode.....	51
Match String.....	51
Wrong Code String	51
Case Conversion	52
Global Prefix	52
Global Suffix	52
No Read String	52
Transmit AIM IDs	53
Transmit Custom Label IDs	53
Custom Label Identifiers	53
Custom Label Identifiers (continued).....	54
Custom Label Identifiers (continued).....	55
Custom Code Identifiers (continued).....	56
DIGITAL OUTPUTS	57
Output 1 Activation Event	58
Output 1 Deactivation Event.....	58
Output 1 Deactivation Timeout	58
Output 1 Activation Event	58
Output 2 Activation Event	59
Output 2 Deactivation Event.....	59
Output 2 Deactivation Timeout	59
Output 2 Activation Event	59
POWER SAVE	60
Sleep Mode Timeout.....	61
CODE SELECTION	62
UPC-A.....	63

Check Character Tx.....	63
Expand to EAN-13.....	63
Number System Tx.....	63
UPC-A Minimum Reads.....	64
Coupon Control.....	64
UPC-E.....	65
Check Character Tx.....	65
Expand to UPC-A.....	65
Expand to EAN-13.....	65
Number System Tx.....	66
UPC-E Minimum Reads.....	66
EAN-13.....	67
Check Character Tx.....	67
ISBN Conversion.....	67
ISSN Conversion.....	67
Flag 1 Character.....	68
EAN-13 Minimum Reads.....	68
Coupon Control.....	68
EAN-8.....	69
Check Character Tx.....	69
Expand to EAN-13.....	69
EAN-8 Minimum Reads.....	69
Enable Optional P2 Add-On.....	70
Enable Optional P5 Add-On.....	70
P2 Minimum Reads.....	70
P5 Minimum Reads.....	71
Optional Add-On Timer.....	71
GTIN Format.....	72
Decoding Level.....	72
Character Correlation.....	72
In-Store Minimum Reads.....	73
Code 39.....	73
Code 39 Full ASCII.....	73
Code Length Control.....	73
Set Length.....	74
Code 39 Check Tx.....	74
Code 39 Start/Stop Tx.....	74
Code 32 (Italian Pharmaceutical).....	75
Code 32 Check Tx.....	75
Code 32 Start/Stop Tx.....	75
Check Calculation.....	76
Minimum Reads.....	76
Decoding Level.....	77
Character Correlation.....	77
Interdigit Ratio.....	77
Quiet Zones.....	78
Stitching.....	78
Code 128.....	79
GS1-128 Enable.....	79
Code Length Control.....	79
Set Length.....	79
Expand to Code 39.....	80
Check Tx.....	80
Function Character Tx.....	80
Sub-Code Change Tx.....	80

Minimum Reads.....	81
Decoding Level	81
Character Correlation	82
Quiet Zones	82
Stitching	82
ISBT 128 Concatenation.....	83
Concatenation Mode.....	83
Dynamic Concatenation Timeout.....	83
Interleaved 2 of 5	84
Code Length Control.....	84
Set Length	84
Check Calculation.....	85
Check Tx.....	85
Minimum Reads.....	86
Decoding Level	86
Character Correlation	87
Stitching	87
Zero Pattern.....	87
Standard 2 of 5	88
Code Length Control.....	88
Set Length	88
Check Calculation.....	88
Check Tx.....	89
Minimum Reads.....	89
Decoding Level	90
Character Correlation	90
Stitching	90
Codabar	91
Code Length Control.....	91
Set Length	91
Codabar ABC.....	92
Concatenation Mode.....	92
Dynamic Concatenation Timeout.....	92
Check Calculation.....	93
Check Tx.....	93
Start/Stop Set	93
Start/Stop Tx.....	94
Start/Stop Match	94
Minimum Reads.....	94
Decoding Level	95
Character Correlation	95
Interdigit Ratio.....	95
Quiet Zones	96
Stitching	96
Code 11	97
Code Length Control.....	97
Set Length	97
Check Calculation.....	98
Check Tx.....	98
Minimum Reads.....	99
Decoding Level	99
Character Correlation	100
Interdigit Ratio.....	100
Stitching	100
GS1 DataBar Omnidirectional	101

GS1 DataBar Omnidirectional GS1-128 Emulation	101
Minimum Reads.....	101
GS1 DataBar Expanded	102
GS1 DataBar Expanded GS1-128 Emulation.....	102
Code Length Control.....	102
Set Length	102
Minimum Reads.....	103
Coupon Control.....	103
GS1 DataBar Limited.....	104
GS1 DataBar Limited GS1-128 Emulation	104
Minimum Reads.....	104
Code 93	105
Code Length Control.....	105
Set Length	105
Check Calculation.....	106
Check Tx.....	106
Minimum Reads.....	107
Decoding Level	107
Character Correlation	108
Quiet Zones	108
Stitching	108
MSI	109
Code Length Control.....	109
Set Length	109
Check Calculation.....	110
Check Tx.....	110
Minimum Reads.....	111
Decoding Level	111
Stitching	112
5 PARAMETER REFERENCES	113
5.1 RS232 Parameters	113
5.1.1 RS232 Only	113
5.1.2 RS232/USB COM Parameters	114
5.2 Reading Parameters.....	118
5.2.1 Illumination Mode.....	118
5.2.2 Operating Mode	119
5.2.3 Good Read LED	122
5.3 Data Formatting	123
5.3.1 Global Prefix/Suffix	124
5.3.2 Code Identifiers.....	126
5.3.3 Code Verifier.....	129
5.4 Digital Outputs	130
5.5 Power Save	131
5.6 Code Selection	131
5.6.1 Concatenation.....	133
5.6.2 Set Length	134
6 TECHNICAL FEATURES.....	136
6.1 Reading Diagrams	137
A DEFAULT PARAMETERS TABLE.....	138
B KEYPAD.....	142

C	ASCII/HEX/DECIMAL CHART	144
D	RESERVED CHARACTERS.....	146

REFERENCES

CONVENTIONS

This manual uses the following conventions:

“User” or “Operator” refers to anyone using a TC1200.

“Device” refers to the TC1200.

“You” refers to the System Administrator or Technical Support person using this manual to install, mount, operate, maintain or troubleshoot a TC1200.

REFERENCE DOCUMENTATION

The documentation related to the TC1200 management is listed below:

- GFC-TC1200 Installation Manual
- Datalogic Aladdin™ Help On Line

SERVICES AND SUPPORT

Datalogic provides several services as well as technical support through its website. Log on to **www.automation.datalogic.com** and click on the links indicated for further information:

- **PRODUCTS**

Search through the links to arrive at your product page which describes specific Info, Features, Applications, Models, Accessories, and Downloads including the Datalogic Aladdin™ utility program, which allows device configuration using a PC. It provides RS232 and USB-COM interface configuration.

- **SERVICE**

- **Overview** - Warranty Extensions and Maintenance Agreements
- **Sales Network**- Listing of Subsidiaries, Repair Centers, Partners
- **Helpdesk**
- **Material Return Authorization**

PATENTS

This product is covered by one or more of the following patents:

US Patents: 5,144,118; 5,311,000; 5,481,098; 5,493,108; 5,929,421; 5,992,740; 6,098,883; 6,260,764; 6,443,360 B1; 6,631,846 B2; 6,808,114 B1; 6,817,525 B2; 6,997,385 B2; 7,075,663 B2; 7,387,246 B2.

European Patents: 789,315 B1; 926,620 B1; 962,880 B1; 997,760 B1; 1,128,315 B1; 1,164,536 B1; 1,217,571 B1; 1,396,811 B1; 1,413,971 B1.

Additional patents pending.

SAFETY AND COMPLIANCE NOTICES

FCC COMPLIANCE

Modifications or changes to this equipment without the expressed written approval of Datalogic could void the authority to use the equipment.

This device complies with PART 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference which may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

POWER SUPPLY

This product is intended to be installed by Qualified Personnel only.

This accessory device is intended to be supplied by a UL Listed or CSA Certified Power Unit with «Class 2» or LPS power source, which supplies power directly to the scanner via the 9-pin or USB connector.

CE COMPLIANCE


Warning:

This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.


HANDLING

The TC1200 is designed to be used in an industrial environment and is built to withstand vibration and shock when correctly installed, however it is also a precision product and therefore before and during installation it must be handled correctly to avoid damage.


- avoid that the scanners hit one another causing damage. They should be handled separately.



- avoid that the scanners are dropped (exceeding shock limits).



- do not fine tune the positioning by striking the scanner or bracket.



- do not weld the scanner into position which can cause electrostatic, heat or output window damage.



- do not spray paint near the scanner which can cause output window damage.



1 INTRODUCTION

The TC1200 compact CCD reader is the perfect solution for many OEM applications. It contains a built-in decoder and multi-standard interface. Due to its well-balanced mix of technical characteristics it is perfect for integration into custom equipment, setting a new standard in this product class.

This Reference Manual provides connection diagrams, default parameter listing, complete application parameter settings, specific technical features and reading diagrams.

1.1 CONFIGURATION METHODS

1.1.1 Configuration Using Datalogic Aladdin™ (for RS232/USB-COM Interfaces)

The easiest way to configure TC1200 is by using the **Datalogic Aladdin™** utility program downloadable from: www.automation.datalogic.com.

Aladdin allows you to program the TC1200 reader by selecting configuration commands through a user-friendly graphical interface running on a PC. These commands are sent to the reader over the selected communication interface, or they can be printed as barcodes to be scanned.

Aladdin also provides Help On-Line files explaining how to use the program as well as descriptions of the configuration parameters.

Aladdin also provides the ability to perform a software upgrade for the connected device (see the Datalogic Aladdin™ Help On-Line for more details).

1.1.2 Configuration Using Serial Programming Strings (for RS232/USB-COM Interfaces)

This manual contains the complete set of command strings for TC1200 configuration. These strings can be sent via the RS232/USB-COM interface using a terminal emulator such as HyperTerminal.

Refer to Chapter 3 of this manual for configuration procedures using Serial Strings sent by the Host.

1.1.3 Configuration Using Programming Barcode Labels (for all Interfaces)


Refer to Chapter 4 of this manual for configuration procedures using Programming Barcode Labels.

1.2 BUTTON AND LED INDICATORS

On the face of the TC1200 scanner a keypad is present with a button and three indicator LEDs which are described in the table below.



TC1200 Scanner



TC1200 Keypad

INDICATORS	Color	MEANING
POWER LED	Blue	ON = Power ON
		OFF = Power OFF or standby (only USB model)
GOOD Read LED	Green	ON = Good Read
		OFF = No Read
		Blinks = USB enumeration
TRIGGER LED	Yellow	ON = External trigger or button pressed
		OFF = No trigger
Button		Press for manual trigger

1.3 AVAILABLE MODELS

The TC1200 reader is available in models that differ in regard to the following characteristics:

- Output Interface
- Enclosure

The following models are therefore available:


- **TC1200-1000** CCD Reader, RS232
- **TC1200-1100** CCD Reader, USB
- **TC1200-0000** Scan Engine CCD Reader, RS232
- **TC1200-0100** Scan Engine CCD Reader, USB

2 INSTALLATION

2.1 TC1200 CCD SCANNER

2.1.1 Mechanical Installation

The diagram below gives the overall dimensions of the reader and may be used for its installation.



2.1.2 Electrical Connections

The TC1200-1000 Scanner is equipped with a 9-pin Male D-Sub connector for connection to the power supply and input/output signals. The details of the connector pins are indicated in the following table:




Figure 2 - 9-pin Male D-sub Connector

9-pin Connector		
1	VCC	+5Vdc
2	GND	Ground
3	RX	Receive Data
4	TX	Transmit Data
5	OUT1 +	Output signal 1, positive
6	OUT1/2 -	Output signal 1/2, negative
7	OUT2 +	Output signal 2, positive
8	EXT-TRIG +	External Trigger Input, positive
9	EXT-TRIG -	External Trigger Input, negative

Table 1 - TC1200-1000 Scanner Pinout

The TC1200-1100 Scanner is equipped with a USB Type A connector for connection to the PC standard USB Port. The details of the connector pins are indicated in the following table:



Figure 3 – USB Type A Connector

USB Type A Connector		
1	VCC	+5 Vdc
2	DATA -	USB Data, negative
3	DATA +	USB Data, positive
4	GND	Ground

Table 2 - TC1200-1100 Scanner Pinout

RS232 Interface

The TC1200-1000 Scanner can communicate with the Host using the RS232 signals provided on the 9-pin connector. The pins are indicated in Table 1 and in the following diagram:

It is always advisable to use shielded cables. The overall maximum cable length must be less than 15 m (49.2 ft).




Figure 3 - RS232 Interface Connection to Host

Inputs

There is an input available on the TC1200-1000 Scanner relative to the External Trigger used to signal the reading phase for On Line Operating Mode. The pins are indicated in Table 1. This input is optocoupled and can be driven by both an NPN or PNP type command. The connections are indicated in the following diagrams:




Figure 4 - Input NPN Command Using External Power




Figure 5 - Input PNP Command Using External Power




Figure 6 - Input NPN Command Using TC1200 Power




Figure 7 - Input PNP Command Using TC1200 Power

The External Trigger Input can also be activated by the external button (Push Button = Trigger On).

Outputs

There are two outputs available on the TC1200-1000 Scanner. Each output can be activated on one of the following events: Good Read, No Read, Wrong Code.

The active level (high or low) of each Output can also be configured in software.

The pins are indicated in Table 1. The connections are indicated in the following diagram:




Figure 4 – Output1 Connection. Example NPN




Figure 9 – Output2 Connection. Example NPN

2.2 TC1200 CCD SCAN ENGINE

2.2.1 Mechanical Installation

The diagram below gives the overall dimensions of the TC1200 Scan Engine and may be used for its installation.




Figure 10 - Overall Dimensions

2.2.2 Electrical Connections

The TC1200-0X00 Scan Engine is equipped with an 8-pin and a 10-pin DF13 connector for connection to the power supply and input/output signals. The details of the connector pins are indicated in the following table:




Figure 5 – 10 and 8-pin Connectors

J1		
Pin	Signal	Description
1	D-	USB Data negative
2	D+	USB Data positive
3	GND	power ground
4	GND	power ground
5	TX	transmit data
6	RTS	NOT USED
7	RX	receive data
8	CTS	NOT USED
9	VCC	+5Vdc
10	GND	power ground

J2		
Pin	Signal	Description
1	GND	power ground
2		NC
3	OUT2+	Output 2 positive
4	OUT1/2-	Output 1/2 negative
5	OUT1+	Output 1 positive
6		NC
7	EXT TRIG-	External Trigger Input positive
8	EXT TRIG+	External Trigger Input negative

Table 3 - TC1200 Scan Engine Pinout

RS232 Interface

The TC1200-0000 Scan Engine can communicate with the Host using the RS232 signals provided on the J1 connector. The pins are indicated in Table 1 and in the following diagram:

It is always advisable to use shielded cables. The overall maximum cable length must be less than 15 m (49.2 ft).




Figure 12 - RS232 Interface Connection to Host

USB Interface

The TC1200-0100 Scan Engine can communicate with the Host using the USB signals provided on the J1 connector. The pins are indicated in Table 1 and in the following diagram:

It is always advisable to use shielded cables. The overall maximum cable length must be less than 15 m (49.2 ft).




Figure 13 - USB Interface Connection to Host

Inputs

There is an input available on the TC1200-0000 Scan Engine relative to the External Trigger used to signal the reading phase for On Line Operating Mode. The pins are indicated in Table 1. This input is optocoupled and can be driven by both an NPN or PNP type command. The connections are indicated in the following diagrams:




Figure 14 - Input NPN Command Using External Power




Figure 15 - Input PNP Command Using External Power




Figure 15 - Input NPN Command Using TC1200 Power




Figure 16 - Input PNP Command Using TC1200 Power

Outputs

There are two outputs available on the TC1200-0000 Scan Engine. Each output can be activated on one of the following events: Good Read, No Read, Wrong Code.

The active level (high or low) of each Output can also be configured in software.

The pins are indicated in Table 1. The connections are indicated in the following diagram:




Figure 17 – Output1 Connection. Example NPN




Figure 18 – Output2 Connection. Example NPN

2.3 POSITIONING

The TC1200 Scanner is able to decode barcode labels at a variety of angles, however significant angular distortion may degrade reading performance.

When mounting the TC1200 take into consideration these three ideal label position angles: **Pitch 0°**, **Skew 10° to 30°** and **Tilt 0°**. Follow the suggestions for the best orientation:

The **Pitch** angle is represented by the value **P** in the figure. Position the reader in order to **minimize** the **Pitch** angle.




Figure 19 - Pitch Angle

The **Skew** angle is represented by the value **S** in the figure. Position the reader to **assure at least 10°** for the **Skew** angle. This avoids direct light reflection.




Figure 20 - Skew angle

The **Tilt** angle is represented by the value **T** in the figure. Position the reader in order to **minimize** the **Tilt** angle.




Figure 21 - Tilt angle

3 SOFTWARE CONFIGURATION STRINGS

3.1 TC1200 CONFIGURATION

TC1200 RS232 models (as well as USB models having the USB-COM Interface selected), can be configured using the serial strings contained in this chapter:

To configure TC1200 RS232 models by using the configuration strings:

- 1) Connect your TC1200 to a PC RS232 port according to the information in [chapter 2](#). Set the PC serial port to the TC1200 default RS232 communication parameters (see [Appendix A](#)).



NOTE

To configure the reader using configuration strings, you must enter Service Mode which automatically sets the reader communication to 115200 baudrate. You must therefore set the host accordingly for RS232 communications. Upon exiting Service Mode, the programmed baud rate will be restored.

- 2) Using a Terminal Emulation Program, send the Restore Current Interface Default string to the reader using the syntax described on the next page.
- 3) Send all the necessary command strings according to your application's requirements.

To configure TC1200 USB models (only for USB-COM Interface) by using the configuration strings:



NOTE

USB models by default have the USB-KBD Interface selected and are easily configured by reading the barcodes in chapter 4.

- 1) Download and install the USB-COM driver from the TC1200 product page at www.automation.datalogic.com.
- 2) Connect your TC1200 to a PC USB port according to the information in [chapter 2](#).
- 3) Change the interface to USB-COM by reading the barcode below.

USB-COM



- 4) Using a Terminal Emulation Program, send the Restore Current Interface Default string to the reader using the syntax described on the next page.
- 5) Send all the necessary command strings according to your application's requirements.

Command Syntax

1. Enter Service (Serial String Programming) Mode

\$S<CR>

This command automatically sets the reader communication to 115200 baudrate.

2. Send Command

\$	Command	Parameter	Value	<CR>
----	---------	-----------	-------	------

Where:

Command:	Description
HA XX	Interface Selection
AA	Enable All Symbolologies
AD	Disable All Symbolologies
R	Reset Reader
C XXXXXX	Write Single Configuration Item to RAM
Parameter:	
XXXX	A 4-character ASCII string See Serial Configuration Strings Table
Value:	
XX	A 2-character Hex string See Serial Configuration Strings Table

3. Apply and Save Configuration to FLASH (permanent memory) and Exit Service Mode

\$Ar<CR>

This command automatically returns to the programmed baudrate.

Example 1:

1. **\$S<CR>**
Enter Service Mode
2. **\$CLFCA02<CR>**
Write command "Convert to Lower Case" to current configuration
3. **\$Ar<CR>**
Apply and Save Configuration to FLASH (permanent memory) and Exit Service Mode.

Each configuration parameter setting removes the condition previously active for that parameter.

Example 2:

1. **\$S<CR>**
Enter Service Mode
2. **\$HA05<CR>**
Select RS232 Interface
3. **\$Ar<CR>**
Apply and Save Configuration to FLASH (permanent memory) and Exit Service Mode.

Example 3:

1. **\$+\$!<CR>**
Read Application Software Release

SERIAL CONFIGURATION STRINGS

ENTER/EXIT CONFIGURATION COMMANDS	
Description	Command
Enter Service Mode (configuration) fixed 115200 Baud rate	S
Exit Service Mode (configuration) return to programmed Baud rate	s
Apply Configuration to RAM (temporary memory) and Exit Service Mode	r01
Apply and Save Configuration to FLASH (permanent memory) and Exit Service Mode	Ar



NOTE

To configure the reader using configuration strings, you must enter Service Mode which automatically sets the reader communication to 115200 baudrate. You must therefore set the host accordingly for RS232 communications. Upon exiting Service Mode, the programmed baud rate will be restored.

CONFIGURATION COMMANDS	
Description	Command
Write Single Configuration Item to RAM (temporary memory)	Cxxxxxx
Read Single Configuration Item from RAM (temporary memory)	cxxxx
Reset Reader	R
Read Application Software Release (does not require Enter/Exit Service Mode)	\$+\$!
Host Commands Obey	CIFIH00
Host Commands Ignore	CIFIH01
Enable all Symbologies	AA
Disable all Symbologies	AD



NOTE

To read a particular parameter setting from the reader, send the read parameter command without any value. The reader will respond with its currently configured value.



NOTE

The Read Application Software Release command is a direct command that does not require entering Service Mode.

INTERFACE SELECTION COMMANDS	
Description	Command
Restore Custom Default Configuration	HA00
RS232	HA05
USB-COM	HA47
USB-KBD	HA35
USB-KBD-ALT	HA2B
USB KBD-APPLE	HA2C



NOTE

The Interface Selection commands store and load the new interface type with its factory defaults into the current configuration.

RS232 ONLY PARAMETERS			
Description		Parameter	Value
Baud Rate	1200	R2BA	00
	2400		01
	4800		02
	9600		03
	19200		04
	38400		05
	57600		06
	115200		07
Parity	none	R2PA	00
	even		01
	odd		02
Data Bits	7	R2DA	00
	8		01
Stop Bits	1	R2ST	00
	2		01

RS232/USB-COM PARAMETERS			
Description		Parameter	Value
Intercharacter Delay	No delay or from 10 to 990 ms	R2IC	a
Disable Character	host command character which disables the reader	R2DC	b
Enable Character	host command character which enables the reader	R2EC	b
ACK/NAK Options	disable	R2AE	00
	enable for label transmission		01
	enable for host command acknowledge		02
	enable for label transmission and host command acknowledge		03
ACK Character	Selects character to be used as ACK	R2AC	c
NAK Character	Selects character to be used as NAK	R2NA	c
ACK/NAK Timeout Value	No timeout or from 200 to 15000 ms	R2AT	d
ACK/NAK Retry Count	From 0 to unlimited retries	R2AR	e
ACK/NAK Error Handling	Ignore errors detected	R2EH	00
	Process errors as valid ACK character		01
	Process errors as valid NAK character		02

a = Hex value from **00** to **63** representing the decimal number (00 = no delay; all others x10 ms)

b = Hex value from **00** to **FE** representing the ASCII character

c = Hex value from **00** to **FF** representing the ASCII character

d = Hex value from **00** to **4B** representing the decimal number (00 = timeout disabled; all others x200 ms)

e = Hex value from **00** to **FF** representing the number of retries (00 = no retries; 01-FE = 1-254 retries; FF = unlimited retries)

USB-KBD / USB-KBD-ALT / USB-KBD-APPLE PARAMETERS			
Description		Parameter	Value
Keyboard Country Mode	*US	KBCO	00
	*Belgium		01
	*Britain		02
	Croatia		11
	Czechoslovakia		0E
	Denmark		03
	*France		04
	*Germany		05
	Hungary		0D
	*Italy		06
	Japanese (106 key)		0C
	Norway		07
	Poland		12
	Portugal		08
	Romania		10
	Slovakia		0F
	*Spain		09
	*Sweden		0A
	Switzerland		0B
Keyboard Intercode Delay	No delay or from 1 to 99 seconds	KBID	f
Send Control Characters	CTRL + KEY	KBSC	00
	CTRL + SHIFT + KEY		01
	Special Function KEY		02
USB Keyboard Speed	1 ms	KBSP	01
	2 ms		02
	3 ms		03
	4 ms		04
	5 ms		05
	6 ms		06
	7 ms		07
	8 ms		08
	9 ms		09
	10 ms		0A

f = Hex value from **00** to **63** representing the decimal number (00 = no delay; all others x1 s)

* = Valid for USB-KBD-APPLE

READING PARAMETERS PARAMETERS			
Description		Parameter	Value
Illumination Mode	Disabled	SPIL	00
	Triggered		01
	Enabled		02
Operating Modes	On Line	SNRM	00
	Serial On Line		01
	Automatic		02
	Automatic (Object Sense)		03
	Test		04
Automatic Threshold	From 2 to 255 scans without a code	SNAT	g
Phase Off Event	Trigger Stop	SNT0	00
	Timeout		01
	Trigger Stop-Timeout		02
Timeout	From 40 to 5100 ms	SNET	h
Serial Start	Any string of characters (<i>max 20</i>) between 00-FE	STON	i
Serial Stop	Any string of characters (<i>max 20</i>) between 00-FE	STOF	i
LED Indication	On Decode	BPIN	00
	After Transmission		01
Label Programming Mode	Disabled	FAPM	00
	Enabled		01

g = Hex value from **02** to **FF** representing the number of scans without a code

h = Hex value from **02** to **FF** representing the decimal number (x20 ms)

i = Hex value from **00** to **FE** representing the ASCII character

DATA FORMAT			
Description		Parameter	Value
Data Transmission	On Decode	LFTX	01
	After Phase Off		00
Code Verifier Mode	Disabled	LFCV	00
	Transmit Wrong String		01
	Transmit Wrong Code		02
Match String	Any string of characters (max 20) between 00-FE	COVS	k
Wrong Code String	Any string of characters (max 20) between 00-FE	WCVS	k
Case Conversion	Disable	LFCA	00
	Upper Case		01
	Lower Case		02
Global Prefix (Header)	Any string of characters (max 20) between 00-FE	LFPR	k
Global Suffix (Terminator)	Any string of characters (max 20) between 00-FE	LFSU	k
No Read String	Any string of characters (max 20) between 00-FE	NORS	k
Character Conversion	An 8-character string between 00-FF	LFCH	m
Transmit AIM IDs	Disable	AIEN	00
	Enable		01
Transmit Custom Label IDs	Disable	IDCO	00
	Prefix		01
	Suffix		02
GS1-128 AIM ID	Disable	U8AI	00
	Enable		01

k = Hex value from 00 to FE representing the ASCII character

m = 8 Hex values from 00 to FF representing the 8 ASCII characters (FF = no replacement or ignore)

Custom Code Identifiers	Any string of characters (max 3) between 00-FE		
UPC-A		ABID	k
UPC-E		EBID	k
EAN-8		8BID	k
EAN-13		3BID	k
UPC-A/P2		A2ID	k
UPC-A/P5		A5ID	k
UPC-E/P2		E2ID	k
UPC-E/P5		E5ID	k
EAN-8/P2		82ID	k
EAN-8/P5		85ID	k
EAN-13/P2		32ID	k
EAN-13/P5		35ID	k
ISBN		ISID	k
ISSN		INID	k
GTIN for EAN/UPC w/o Add-On		GBID	k
GTIN for EAN/UPC w P2		G2ID	k
GTIN for EAN/UPC w P5		G5ID	k
Code 39		C3ID	k
Code 32		P3ID	k
Code 128		C8ID	k
GS1-128		U8ID	k
ISBT 128		I8ID	k
Interleaved 2 of 5		I2ID	k
Standard 2 of 5		S2ID	k
Codabar		CBID	k
ABC Codabar		ACID	k
Code 11		C1ID	k
GS1 Databar 14 (Omnidirectional)		4BID	k
GS1 Databar Expanded		XBID	k
GS1 Databar Limited		LBID	k
Code 93		C9ID	k
MSI		MSID	k

k = Hex value from 00 to FE representing the ASCII character

DIGITAL OUTPUTS			
Description		Parameter	Value
OUTPUT 1			
Activation Event	Disable	OUA1	00
	Good Read		01
	No Read		02
	Wrong Code		03
Deactivation Event	Disable	OUD1	00
	Timeout		01
	Reading Phase Active		02
Deactivation Timeout	100 to 25500 ms	OUT1	<i>n</i>
Active Level	Closed	OUL1	00
	Open		01
OUTPUT 2			
Activation Event	Disable	OUA2	00
	Good Read		01
	No Read		02
	Wrong Code		03
Deactivation Event	Disable	OUD2	00
	Timeout		01
	Reading Phase Active		02
Deactivation Timeout	100 to 25500 ms	OUT2	<i>n</i>
Active Level	Closed	OUL2	00
	Open		01

n = Hex value from 01 to FF representing the decimal number (x100 ms)

POWER SAVE			
Description		Parameter	Value
Sleep Mode Timeout	Disable	SLTO	00
	10 seconds		01
	30 seconds		02
	1 minute		03
	5 minutes		04
	10 minutes		05

CODE SELECTION			
Description		Parameter	Value
UPC-A			
UPC-A	Disable	ABEN	00
	Enable		01
Check Character Tx	Disable	ABCT	00
	Enable		01
Expand to EAN-13	Disable	AB3B	00
	Enable		01
Number System Tx	Disable	ABNS	00
	Enable		01
Minimum Reads	One Read	ABMR	01
	Two Reads		02
	Three Reads		03
	Four Reads		04
Coupon Control	Allow all coupon barcodes to be decoded	CPCL	00
	Enable only UPC-A coupon decoding		01
	Enable only GS1 Databar coupon decoding		02
UPC-E			
UPC-E	Disable	EBEN	00
	Enable		01
Check Character Tx	Disable	EBCT	00
	Enable		01
Expand to UPC-A	Disable	EBAB	00
	Enable		01
Expand to EAN-13	Disable	EB3B	00
	Enable		01
Number System Tx	Disable	EBNS	00
	Enable		01
Minimum Reads	One Read	EBMR	01
	Two Reads		02
	Three Reads		03
	Four Reads		04
EAN-13			
EAN-13	Disable	3BEN	00
	Enable		01
Check Character Tx	Disable	3BCT	00
	Enable		01
ISBN Conversion	Disable	3BIS	00
	Enable		01
ISSN Conversion	Disable	3BIN	00
	Enable		01
Flag 1 Character	Disable	3BF1	00
	Enable		01
Minimum Reads	One Read	3BMR	01
	Two Reads		02
	Three Reads		03
	Four Reads		04
Coupon Control	Allow all coupon barcodes to be decoded	CPCL	00
	Enable only UPC-A coupon decoding		01
	Enable only GS1 Databar coupon decoding		02
EAN-8			
EAN-8	Disable	8BEN	00
	Enable		01
Check Character Tx	Disable	8BCT	00
	Enable		01
Expand to EAN-13	Disable	8B3B	00
	Enable		01
Minimum Reads	One Read	8BMR	01
	Two Reads		02
	Three Reads		03
	Four Reads		04

CODE SELECTION			
Description		Parameter	Value
Add-Ons			
P2 Add-On	Disable	ADO2	00
	Enable		01
P5 Add-On	Disable	ADO5	00
	Enable		01
P2 Minimum Reads	One Read	ADM2	01
	Two Reads		02
	Three Reads		03
	Four Reads		04
P5 Minimum Reads	One Read	ADM5	01
	Two Reads		02
	Three Reads		03
	Four Reads		04
Optional Add-On Timer	Timer disabled or from 10 to 300 ms	ADOT	p
EAN/UPC Global Settings			
GTIN Format	Disable	GBEN	00
	Enable		01
Decoding Level	Disable	UNDL	00
	Level 1		01
	Level 2		02
	Level 3		03
	Level 4		04
	Level 5		05
Character Correlation	Disable	UNCO	00
	Enable		01
In-Store Minimum Reads	One Read	INMR	01
	Two Reads		02
	Three Reads		03
	Four Reads		04

p = Hex value from 00 to 1E representing the decimal number (00 = Timer disabled; all others x10 ms)

CODE SELECTION			
Description		Parameter	Value
Code 39			
Code 39	Disable	C3EN	00
	Enable		01
Code 39 Full ASCII	Disable	C3FA	00
	Enable		01
Code Length Control	Variable	C3LC	00
	Fixed		01
Set Length	Length 1 (or Min Length) from 1 to 50 characters	C3L1	q
	Length 2 (or Max Length) 0 or from 1 to 50 characters	C3L2	q
Code 32 (Italian Pharma)	Disable	P3EN	00
	Enable		01
Code 32 Check Tx	Disable	P3CT	00
	Enable		01
Code 32 Start/Stop Tx	Disable	P3SS	00
	Enable		01
Check Options			
Check Calculation	Disable	C3CC	00
	Enable Standard Check		01
	Enable Mod-7 Check		02
	Enable Italian Post Check		04
	Enable Daimler Chrysler Check		08
Code 39 Check Tx	Disable	C3CT	00
	Enable		01
Code 39 Start/Stop Tx	Disable	C3SS	00
	Enable		01
Decoding Options			
Minimum Reads	One Read	C3MR	01
	Two Reads		02
	Three Reads		03
	Four Reads		04
Decoding Level	Disable	C3DL	00
	Level 1		01
	Level 2		02
	Level 3		03
	Level 4		04
	Level 5		05
Interdigit Ratio	Any ratio or 1 to 10	C3IR	r
Character Correlation	Disable	C3CO	00
	Enable		01
Quiet Zones	Quiet Zone on One Side	C3LO	01
	Quiet Zones on Two Sides		02
	Auto		03
	Virtual Quiet Zones on Two Sides		04
	Small Quiet Zones on Two Sides		05
Stitching	Disable	C3ST	00
	Enable		01

q = Hex value from **00** to **32** representing the decimal number

r = Hex value from **00** to **0A** representing the decimal number of the interdigit space/module ratio (00 = any ratio)

CODE SELECTION			
Description		Parameter	Value
Code 128 (GS1-128)			
Code 128	Disable	C8EN	00
	Enable		01
GS1-128 Enable	Enable (transmit labels in Code 128 data format)	U8EN	00
	Enable (transmit labels in GS1-128 data format)		01
	Disable		02
Code Length Control	Variable	C8LC	00
	Fixed		01
Set Length	Length 1 (or Min Length) from 1 to 80 characters	C8L1	s
	Length 2 (or Max Length) 0 or from 1 to 80 characters	C8L2	s
Expand to Code 39	Disable	C8C3	00
	Enable		01
Check Options			
Check Tx	Disable	C8CT	00
	Enable		01
Function Character Tx	Disable	C8TF	00
	Enable		01
Sub-Code Change Tx	Disable	C8SC	00
	Enable		01
Decoding Options			
Minimum Reads	One Read	C8MR	01
	Two Reads		02
	Three Reads		03
	Four Reads		04
Decoding Level	Disable	C8DL	00
	Level 1		01
	Level 2		02
	Level 3		03
	Level 4		04
	Level 5		05
Character Correlation	Disable	C8CO	00
	Enable		01
Quiet Zones	No Quiet Zones	C8LO	00
	Quiet Zone on One Side		01
	Quiet Zones on Two Sides		02
	Auto		03
	Virtual Quiet Zones on Two Sides		04
Stitching	Disable	C8ST	00
	Enable		01
ISBT 128			
ISBT 128 Concatenation	Disable	I8CE	00
	Enable		01
Concatenation Mode	Static	I8CM	00
	Dynamic		01
Dynamic Concat. Timeout	From 50 to 2550 ms	I8DT	t
Chain 0 - Chain 15	Contact Datalogic		

s = Hex value from 00 to 50 representing the decimal number

t = Hex value from 05 to FF representing the decimal number (x10 ms)

CODE SELECTION			
Description		Parameter	Value
Interleaved 2 of 5 (I 2 of 5)			
I 2 of 5	Disable	I2EN	00
	Enable		01
Code Length Control	Variable	I2LC	00
	Fixed		01
Set Length	Length 1 (or Min Length) from 2 to 50 characters (only even numbers)	I2L1	v
	Length 2 (or Max Length) from 0 or from 2 to 50 characters (only even numbers)	I2L2	v
Check Options			
Check Calculation	Disable	I2CC	00
	Enable Standard(Mod 10)		01
	Enable German Parcel		02
	Enable DHL		04
	Enable Daimler Chrysler		08
	Enable Bosch		10
	Enable Italian Post		20
Check Tx	Disable	I2CT	00
	Enable		01
Decoding Options			
Minimum Reads	One Read	I2MR	01
	Two Reads		02
	Three Reads		03
	Four Reads		04
Decoding Level	Disable	I2DL	00
	Level 1		01
	Level 2		02
	Level 3		03
	Level 4		04
	Level 5		05
Character Correlation	Disable	I2CO	00
	Enable		01
Stitching	Disable	I2ST	00
	Enable		01
Zero Pattern	Disable	I2ZP	00
	Enable		01

v = Hex value from 00 or 02 to 32 representing the decimal number

Standard 2 of 5			
Standard 2 of 5	Disable	S2EN	00
	Enable		01
Code Length Control	Variable	S2LC	00
	Fixed		01
Set Length	Length 1 (or Min Length) from 1 to 50 characters	S2L1	v
	Length 2 (or Max Length) 0 or from 1 to 50 characters	S2L2	v
Check Options			
Check Calculation	Disable	S2CC	00
	Enable		01
Check Tx	Disable	S2CT	00
	Enable		01
Decoding Options			
Minimum Reads	One Read	S2MR	01
	Two Reads		02
	Three Reads		03
	Four Reads		04
Decoding Level	Disable	S2DL	00
	Level 1		01
	Level 2		02
	Level 3		03
	Level 4		04
	Level 5		05
Character Correlation	Disable	S2CO	00
	Enable		01
Stitching	Disable	S2ST	00
	Enable		01

v = Hex value from 00 to 32 representing the decimal number

CODE SELECTION			
Description		Parameter	Value
Codabar			
Codabar	Disable	CBEN	00
	Enable		01
Code Length Control	Variable	CBLC	00
	Fixed		01
Set Length	Length 1 (or Min Length) from 3 to 50 characters	CBL1	v
	Length 2 (or Max Length) 0 or from 3 to 50 characters	CBL2	v
ABC Codabar			
ABC Codabar	Disable	CBAB	00
	Enable		01
Concatenation Mode	Static	CBCM	00
	Dynamic		01
Dynamic Concat. Timeout	From 50 to 2550 ms	CBDT	t
Check Options			
Check Calculation	Disable	CBCC	00
	Enable AIM Standard Check		01
	Enable Mod-10 Check		02
Check Tx	Disable	CBCT	00
	Enable		01
Start/Stop Set	ABCD/TN*E	CBSC	00
	ABCD/ABCD		01
	abcd/tn*e		02
	abcd/abcd		03
Start/Stop Tx	Disable	CBSS	00
	Enable		01
Start/Stop Match	Disable	CBSM	00
	Enable		01
Decoding Options			
Minimum Reads	One Read	CBMR	01
	Two Reads		02
	Three Reads		03
	Four Reads		04
Decoding Level	Disable	CBDL	00
	Level 1		01
	Level 2		02
	Level 3		03
	Level 4		04
	Level 5		05
Character Correlation	Disable	CBCO	00
	Enable		01
Interdigit Ratio	Any ratio or 1 to 10	CBIR	r
Quiet Zones	Quiet Zone on One Side	CBLO	01
	Quiet Zones on Two Sides		02
	Auto		03
	Virtual Quiet Zones on Two Sides		04
	Small Quiet Zones on Two Sides		05
Stitching	Disable	CBST	00
	Enable		01

v = Hex value from 00 or 03 to 32 representing the decimal number

t = Hex value from 05 to FF representing the decimal number ($\times 10$ ms)

r = Hex value from 00 to 0A representing the decimal number of the interdigit space/module ratio (00 = any ratio)

CODE SELECTION			
Description		Parameter	Value
Code 11			
Code 11	Disable	C1EN	00
	Enable		01
Code Length Control	Variable	C1LC	00
	Fixed		01
Set Length	Length 1 (or Min Length) from 2 to 50 characters	C1L1	v
	Length 2 (or Max Length) 0 or from 2 to 50 characters	C1L2	v
Check Options			
Check Calculation	Disable	C1CC	00
	Enable Check C		01
	Enable Check K		02
	Enable Check C and K		03
Check Tx	Disable	C1CT	00
	Enable		01
Decoding Options			
Minimum Reads	One Read	C1MR	01
	Two Reads		02
	Three Reads		03
	Four Reads		04
Decoding Level	Disable	C1DL	00
	Level 1		01
	Level 2		02
	Level 3		03
	Level 4		04
	Level 5		05
Character Correlation	Disable	C1CO	00
	Enable		01
Interdigit Ratio	1 to 10	C1IR	r
Stitching	Disable	C1ST	00
	Enable		01

v = Hex value from **00** to **32** representing the decimal number

r = Hex value from **00** to **0A** representing the decimal number of the interdigit space/module ratio (00 = any ratio)

GS1 Databar Omnidirectional			
GS1 Databar Omnidirectional	Disable	4BEN	00
	Enable		01
GS1-128 Emulation	Disable	4BU8	00
	Enable		01
Omnidirectional Decoding Options			
Minimum Reads	One Read	4BMR	01
	Two Reads		02
	Three Reads		03
	Four Reads		04
GS1 Databar Expanded			
GS1 Databar Expanded	Disable	XBEN	00
	Enable		01
GS1-128 Emulation	Disable	XBU8	00
	Enable		01
Code Length Control	Variable	XBLC	00
	Fixed		01
Set Length	Length 1 (or Min Length) from 1 to 74 characters	XBL1	w
	Length 2 (or Max Length) 0 or from 1 to 74 characters	XBL2	w
Expanded Decoding Options			
Minimum Reads	One Read	XBMR	01
	Two Reads		02
	Three Reads		03
	Four Reads		04
Coupon Control	Allow all coupon barcodes to be decoded	CPCL	00
	Enable only UPC-A coupon decoding		01
	Enable only GS1 Databar coupon decoding		02
GS1 Databar Limited			
GS1 Databar Limited	Disable	LBEN	00
	Enable		01
GS1-128 Emulation	Disable	LBU8	00
	Enable		01

w = Hex value from 00 to 4A representing the decimal number

CODE SELECTION			
Description		Parameter	Value
GS1 Databar Limited (continued)			
Limited Decoding Options			
Minimum Reads	One Read	LBMR	01
	Two Reads		02
	Three Reads		03
	Four Reads		04
Code 93			
Code 93	Disable	C9EN	00
	Enable		01
Code Length Control	Variable	C9LC	00
	Fixed		01
Set Length	Length 1 (or Min Length) from 1 to 50 characters	C9L1	v
	Length 2 (or Max Length) 0 or from 1 to 50 characters	C9L2	v
Check Options			
Check Calculation	Disable	C9CC	00
	Enable Check C		01
	Enable Check K		02
	Enable Check C and K		03
Check Tx	Disable	C9CT	00
	Enable		01
Decoding Options			
Minimum Reads	One Read	C9MR	01
	Two Reads		02
	Three Reads		03
	Four Reads		04
Decoding Level	Disable	C9DL	00
	Level 1		01
	Level 2		02
	Level 3		03
	Level 4		04
	Level 5		05
Character Correlation	Disable	C9CO	00
	Enable		01
Quiet Zones	No Quiet Zones	C9LO	00
	Quiet Zone on One Side		01
	Quiet Zones on Two Sides		02
	Auto		03
	Virtual Quiet Zones on Two Sides		04
Stitching	Disable	C9ST	00
	Enable		01

v = Hex value from 00 to 32 representing the decimal number

CODE SELECTION			
Description		Parameter	Value
MSI			
MSI	Disable	MSEN	00
	Enable		01
Code Length Control	Variable	MSLC	00
	Fixed		01
Set Length	Length 1 (or Min Length) from 1 to 50 characters	MSL1	v
	Length 2 (or Max Length) 0 or from 1 to 50 characters	MSL2	v
Check Options			
Check Calculation	Disable	MSCC	00
	Enable Mod 10		01
	Enable Mod 11/10		02
	Enable Mod 10/10		03
Check Tx	Disable	MSCT	00
	Enable		01
Decoding Options			
Minimum Reads	One Read	MSMR	01
	Two Reads		02
	Three Reads		03
	Four Reads		04
Decoding Level	Disable	MSDL	00
	Level 1		01
	Level 2		02
	Level 3		03
	Level 4		04
	Level 5		05
Stitching	Disable	MSST	00
	Enable		01

v = Hex value from 00 to 32 representing the decimal number

4 BARCODE CONFIGURATION



CAUTION

The Barcode Configuration is suggested when using USB-KBD interfaces.

4.1 INITIAL SETUP

The following procedure allows preparing your TC1200 to read barcodes by using the default settings.

RESTORE DEFAULT

1. Read the restore factory default parameters code below.

Restore TC1200 Current Interface Default



INTERFACE SELECTION

2. Read the interface selection code for your application.

Only RS232 Models

RS232



Only USB Models

USB-COM



◆ USB-KBD



USB-KBD-ALT



USB-KBD-APPLE



YOUR READER IS NOW READY TO READ BARCODES.

To change the default settings see par. 4.2.

4.2 CHANGING DEFAULT SETTINGS

Once your reader is setup, you can change the default parameters to meet your application needs. Refer to the preceding paragraph for initial configuration in order to set the default values and select the interface for your application.

In this manual, the configuration parameters are divided into logical groups making it easy to find the desired function based on its reference group.

The first three groups are for Standard Interface parameter configuration:

- **RS232**
- **RS232/USB-COM**
- **USB-KBD**

The following parameter groups are common to all interface applications:

READING PARAMETERS control various operating modes and indicator status functioning.

DATA FORMAT parameters regard the messages sent to the Host system for all interfaces.

DIGITAL OUTPUTS manage the events controlling the two digital outputs.

POWER SAVE manages overall current consumption in the reading device.

CODE SELECTION parameters allow configuration of a personalized mix of codes, code families and their options.



GLOBAL INTERFACE FEATURES

◆ Obey Host Commands



Ignore Host Commands



RS232

⊙	BAUD RATE	⊙
⊙	PARITY	⊙
⊙	DATA BITS	⊙
⊙	STOP BITS	⊙

1. Read the **Enter/Exit Configuration** code ONCE, available at the top of each page.
2. Read configuration codes from the desired groups.



= Read the code and follow the procedure on the indicated reference page

◆ = Default value

3. Read the **Enter/Exit Configuration** code ONCE, available at the top of each page.



BAUD RATE**1200 baud****2400 baud****4800 baud****◆ 9600 baud****19200 baud****38400 baud****57600 baud****115200 baud**

PARITY**◆ none****even****odd**



RS232

DATA BITS

7 bits



8 bits



STOP BITS

◆ 1 stop bit



2 stop bits



RS232/USB-COM

⊙	<i>INTERCHARACTER DELAY</i>	⊙
⊙	<i>DISABLE CHARACTER</i>	⊙
⊙	<i>ENABLE CHARACTER</i>	⊙
⊙	<i>ACK/NAK OPTIONS</i>	⊙
⊙	<i>ACK CHARACTER</i>	⊙
⊙	<i>NAK CHARACTER</i>	⊙
⊙	<i>ACK/NAK TIMEOUT</i>	⊙
⊙	<i>ACK/NAK RETRY COUNT</i>	⊙
⊙	<i>ACK/NAK ERROR HANDLING</i>	⊙

1. Read the **Enter/Exit Configuration** code ONCE, available at the top of each page.

2. Read configuration codes from the desired groups.



= Read the code and follow the procedure on the indicated reference page

◆ = Default value

3. Read the Enter/**Exit Configuration** code ONCE, available at the top of each page.



INTERCHARACTER DELAY

◆ No Delay



See page 114

Select Intercharacter Delay



DISABLE CHARACTER

Select Device Disable Character



See page 114

ENABLE CHARACTER

Select Device Enable Character



See page 115

ACK/NAK OPTIONS

◆ Disable

Enable For Host Command
Acknowledge

Enable For Label Transmission

Enable For Label Transmission
And Host Command
Acknowledge

ACK CHARACTER

Select ACK Character



See page 116



NAK CHARACTER**Select NAK Character**

See page 116

ACK/NAK TIMEOUT**◆ No Timeout**

See page 117

Select ACK/NAK Timeout Value

ACK/NAK RETRY COUNT**Select Retry Count**

See page 117

ACK/NAK ERROR HANDLING**Ignore Errors Detected****Process Errors As Valid ACK
Character****Process Errors As Valid NAK
Character**

USB-KBD

⊙	<i>KEYBOARD COUNTRY</i>	⊙
⊙	<i>CAPS LOCK</i>	⊙
⊙	<i>NUM LOCK</i>	⊙
⊙	<i>INTER-CHARACTER DELAY</i>	⊙
⊙	<i>INTER-CODE DELAY</i>	⊙
⊙	<i>KEYBOARD SETTING</i>	⊙
⊙	<i>CONTROL CHARACTER EMULATION</i>	⊙

1. Read the **Enter/Exit Configuration** code ONCE, available at the top of each page.

2. Read configuration codes from the desired groups.



= Read the code and follow the procedure on the indicated reference page

◆ = Default value

3. Read the **Enter/Exit Configuration** code ONCE, available at the top of each page.



KEYBOARD COUNTRY

◆ US



Belgium



Britain



Croatia



Czech Republic



Denmark



France



Germany



Hungary



Italy



Japanese (106 key)



Norway





KEYBOARD COUNTRY (CONTINUED)**Poland****Portugal****Romania****Slovakia****Spain****Sweden****Switzerland**

KEYBOARD INTERCODE DELAY**◆ No Delay**

See page 118

Select Intercode Delay



SEND CONTROL CHARACTERS

◆ CTRL + Key



CTRL + SHIFT + Key



Special Function Key



USB KEYBOARD SPEED

◆ 1 ms



2 ms



3 ms



4 ms



5 ms



6 ms



7 ms



8 ms





USB KEYBOARD SPEED (CONTINUED)

9 ms



10 ms



READING PARAMETERS

⊙	<i>ILLUMINATION MODE</i>	⊙
⊙	<i>OPERATING MODE</i>	⊙
⊙	<i>AUTOMATIC THRESHOLD</i>	⊙
⊙	<i>PHASE OFF EVENT</i>	⊙
⊙	<i>TIMEOUT</i>	⊙
⊙	<i>SERIAL START</i>	⊙
⊙	<i>SERIAL STOP</i>	⊙
⊙	<i>LED INDICATION</i>	⊙
⊙	<i>LABEL PROGRAMMING MODE</i>	⊙

1. Read the **Enter/Exit Configuration** code ONCE, available at the top of each page.

2. Read configuration codes from the desired groups.



= Read the code and follow the procedure on the indicated reference page

◆ = Default value

3. Read the Enter/**Exit Configuration** code ONCE, available at the top of each page.



READING PARAMETERS

ILLUMINATION MODE

Disabled



◆ Triggered



Enabled



OPERATING MODE

◆ On Line



Serial On Line



Automatic



Automatic (Object Sense)



Test



AUTOMATIC THRESHOLD

Select Automatic Threshold



See page 119



PHASE OFF EVENT

◆ Trigger Stop



Timeout



Trigger Stop - Timeout



TIMEOUT

Select Timeout



See page 120

SERIAL START

Select Serial Start Characters



See page 121

SERIAL STOP

Select Serial Stop Characters



See page 121

LED INDICATION

◆ On Decode



After Transmission





READING PARAMETERS

LABEL PROGRAMMING MODE

Disabled



◆ Enabled



DATA FORMAT

⊙	<i>DATA TRANSMISSION</i>	⊙
⊙	<i>CODE VERIFIER MODE</i>	⊙
⊙	<i>MATCH STRING</i>	⊙
⊙	<i>WRONG CODE STRING</i>	⊙
⊙	<i>CASE CONVERSION</i>	⊙
⊙	<i>GLOBAL PREFIX</i>	⊙
⊙	<i>GLOBAL SUFFIX</i>	⊙
⊙	<i>NO READ STRING</i>	⊙
⊙	<i>TRANSMIT AIM IDS</i>	⊙
⊙	<i>TRANSMIT CUSTOM LABEL IDS</i>	⊙
⊙	<i>CUSTOM LABEL IDS</i>	⊙

1. Read the **Enter/Exit Configuration** code ONCE, available at the top of each page.

2. Read configuration codes from the desired groups.



= Read the code and follow the procedure on the indicated reference page

◆ = Default value

3. Read the **Enter/Exit Configuration** code ONCE, available at the top of each page.

**DATA FORMAT**

DATA TRANSMISSION**◆ On Decode****After Phase Off**

CODE VERIFIER MODE**◆ Disabled****Transmit Wrong String****Transmit Wrong Code**

MATCH STRING**Select Match String**

See page 129

WRONG CODE STRING**Select Wrong Code String**

See page 129



CASE CONVERSION**◆ Disable (no case conversion)****Convert To Upper Case****Convert To Lower Case**

GLOBAL PREFIX**Select Global Prefix (Header)**

See page 124

GLOBAL SUFFIX**Select Global Suffix (Terminator)**

See page 124

NO READ STRING**Select No Read String**

See page 125



DATA FORMAT

TRANSMIT AIM IDS

◆ Disable



Enable



TRANSMIT CUSTOM LABEL IDS

◆ Disabled



Prefix



Suffix



CUSTOM LABEL IDENTIFIERS

Set UPC-A Label ID(s)



See page 127

Set UPC-E Label ID(s)



See page 127

Set EAN-8 Label ID(s)



See page 127

Set EAN-13 Label ID(s)



See page 127



CUSTOM LABEL IDENTIFIERS (CONTINUED)

Set UPC-A/P2 Label ID(s)



See page 127

Set UPC-A/P5 Label ID(s)



Set UPC-E/P2 Label ID(s)



See page 127



See page 127

Set UPC-E/P5 Label ID(s)



Set EAN-8/P2 Label ID(s)



See page 127



See page 127

Set EAN-8/P5 Label ID(s)



Set EAN-13/P2 Label ID(s)



See page 127



See page 127

Set EAN-13/P5 Label ID(s)



Set ISBN Label ID(s)



See page 127



See page 127

Set ISSN Label ID(s)



See page 127



DATA FORMAT

CUSTOM LABEL IDENTIFIERS (CONTINUED)

**Set GTIN Label ID(s) for EAN/UPC
without Add-Ons**



See page 127

**Set GTIN Label ID(s) for EAN/UPC
with P2**



**Set GTIN Label ID(s) for EAN/UPC
with P5**



See page 127



See page 127

Set Code 39 Label ID(s)



Set Code 32 Label ID(s)



See page 127



See page 127

Set Code 128 Label ID(s)



Set GS1-128 Label ID(s)



See page 127



See page 127

Set ISBT 128 Label ID(s)



Set Interleaved 2 of 5 Label ID(s)



See page 127



See page 127

Set Standard 2 of 5 Label ID(s)



Set Codabar Label ID(s)



See page 127



See page 127

Set ABC Codabar Label ID(s)



See page 127



CUSTOM CODE IDENTIFIERS (CONTINUED)

Set Code 11 Label ID(s)



See page 127

Set Label ID(s) for GS1 Databar 14 (Omnidirectional)



Set Label ID(s) for GS1 Databar Expanded



See page 127



See page 127

Set Label ID(s) for GS1 Databar Limited



Set Code 93 Label ID(s)



See page 127



See page 127

Set MSI Label ID(s)



See page 127

DIGITAL OUTPUTS

⊙	<i>OUTPUT 1 ACTIVATION EVENT</i>	⊙
⊙	<i>OUTPUT 1 DEACTIVATION EVENT</i>	⊙
⊙	<i>OUTPUT 1 DEACTIVATION TIMEOUT</i>	⊙
⊙	<i>OUTPUT 1 ACTIVE LEVEL</i>	⊙
⊙	<i>OUTPUT 2 ACTIVATION EVENT</i>	⊙
⊙	<i>OUTPUT 2 DEACTIVATION EVENT</i>	⊙
⊙	<i>OUTPUT 2 DEACTIVATION TIMEOUT</i>	⊙
⊙	<i>OUTPUT 2 ACTIVE LEVEL</i>	⊙

1. Read the **Enter/Exit Configuration** code ONCE, available at the top of each page.

2. Read configuration codes from the desired groups.



= Read the code and follow the procedure on the indicated reference page

◆ = Default value

3. Read the Enter/**Exit Configuration** code ONCE, available at the top of each page.



OUTPUT 1 ACTIVATION EVENT

Disable



Good Read



No Read



Wrong Code



OUTPUT 1 DEACTIVATION EVENT

Disable



Timeout



Reading Phase Active



OUTPUT 1 DEACTIVATION TIMEOUT

Set Deactivation Timeout



See page 130

OUTPUT 1 ACTIVATION EVENT

Closed



Open



**DIGITAL OUTPUTS**

OUTPUT 2 ACTIVATION EVENT**Disable****Good Read****No Read****Wrong Code**

OUTPUT 2 DEACTIVATION EVENT**Disable****Timeout****Reading Phase Active**

OUTPUT 2 DEACTIVATION TIMEOUT**Set Deactivation Timeout**

See page 130

OUTPUT 2 ACTIVATION EVENT**Closed****Open**

POWER SAVE



SLEEP MODE TIMEOUT



1. Read the **Enter/Exit Configuration** code ONCE, available at the top of each page.
2. Read configuration codes from the desired groups.



= Read the code and follow the procedure on the indicated reference page

◆ = Default value

3. Read the Enter/**Exit Configuration** code ONCE, available at the top of each page.



POWER SAVE

SLEEP MODE TIMEOUT

Disable



10 Seconds



30 Seconds



1 Minute



5 Minutes



10 Minutes



CODE SELECTION

⊙	<i>EAN/UPC</i>	⊙
⊙	<i>CODE 39 (CODE 32)</i>	⊙
⊙	<i>CODE 128 (GS1-128, ISBT 128)</i>	⊙
⊙	<i>INTERLEAVED 2 OF 5</i>	⊙
⊙	<i>STANDARD 2 OF 5</i>	⊙
⊙	<i>CODABAR (ABC CODABAR)</i>	⊙
⊙	<i>CODE 11</i>	⊙
⊙	<i>GS1 DATA BAR (OMNIDIRECTIONAL, EXPANDED, LIMITED)</i>	⊙
⊙	<i>CODE 93</i>	⊙
⊙	<i>MSI</i>	⊙

1. Read the **Enter/Exit Configuration** code ONCE, available at the top of each page.

2. Read configuration codes from the desired groups.



= Read the code and follow the procedure on the indicated reference page

◆ = Default value

3. Read the Enter/**Exit Configuration** code ONCE, available at the top of each page.

DISABLE ALL CODE SYMBOLOGIES

Use this feature to disable all symbologies.

1. Scan the ENTER/EXIT PROGRAMMING barcode below.
2. Scan the Disable All Symbologies barcode.
3. Complete the programming sequence by scanning the ENTER/EXIT PROGRAMMING barcode.



Disable All Code Symbologies





CODE SELECTION

UPC-A

Disable



Enable



CHECK CHARACTER TX

Disable



Enable



EXPAND TO EAN-13

Disable



Enable



NUMBER SYSTEM TX

Disable



Enable





UPC-A MINIMUM READS**One Read****Two Reads****Three Reads****Four Reads**

COUPON CONTROL**Allow All Coupon Barcodes to be
Decoded****Enable Only UPC-A Coupon
Decoding****Enable Only GS1 Databar Coupon
Decoding**



CODE SELECTION

UPC-E

Disable



Enable



CHECK CHARACTER TX

Disable



Enable



EXPAND TO UPC-A

Disable



Enable



EXPAND TO EAN-13

Disable



Enable



CODE SELECTION

Enter/Exit Configuration



NUMBER SYSTEM TX

Disable



Enable



UPC-E MINIMUM READS

One Read



Two Reads



Three Reads



Four Reads





CODE SELECTION

EAN-13

Disable



Enable



CHECK CHARACTER TX

Disable



Enable



ISBN CONVERSION

Disable



Enable



ISSN CONVERSION

Disable



Enable





FLAG 1 CHARACTER**Disable****Enable**

EAN-13 MINIMUM READS**One Read****Two Reads****Three Reads****Four Reads**

COUPON CONTROL**Allow All Coupon Barcodes to be
Decoded****Enable Only UPC-A Coupon
Decoding****Enable Only GS1 Databar Coupon
Decoding**



CODE SELECTION

EAN-8

Disable



Enable



CHECK CHARACTER TX

Disable



Enable



EXPAND TO EAN-13

Disable



Enable



EAN-8 MINIMUM READS

One Read



Two Reads



Three Reads



Four Reads





ENABLE OPTIONAL P2 ADD-ON

Disable



Enable



ENABLE OPTIONAL P5 ADD-ON

Disable



Enable



P2 MINIMUM READS

One Read



Two Reads



Three Reads



Four Reads





CODE SELECTION

P5 MINIMUM READS

One Read



Two Reads



Three Reads



Four Reads



OPTIONAL ADD-ON TIMER

Add-On Timer Disable



See page 131

Set Add-On Timer Value





GTIN FORMAT

Disable



Enable



DECODING LEVEL

Disable



Level 1



Level 2



Level 3



Level 4



Level 5



CHARACTER CORRELATION

Disable



Enable





CODE SELECTION

IN-STORE MINIMUM READS**One Read****Two Reads****Three Reads****Four Reads**

CODE 39**Disable****Enable**

CODE 39 FULL ASCII**Disable****Enable**

CODE LENGTH CONTROL**Variable****Fixed**

CODE SELECTION



SET LENGTH

Set Length 1
(or Minimum Length)



See page 134



See page 135

Set Length 2
(or Maximum Length)



CODE 39 CHECK TX

Disable



Enable



CODE 39 START/STOP TX

Disable



Enable





CODE SELECTION

CODE 32 (ITALIAN PHARMACEUTICAL)

Disable



Enable



CODE 32 CHECK Tx

Disable



Enable



CODE 32 START/STOP Tx

Disable



Enable



**Code 39 Check Options**

CHECK CALCULATION**Disable****Enable Standard Check****Enable Mod-7 Check****Enable Italian Post Check****Enable Daimler Chrysler Check****Code 39 Decoding Options**

MINIMUM READS**One Read****Two Reads****Three Reads****Four Reads**



CODE SELECTION

DECODING LEVEL

Disable



Level 1



Level 2



Level 3



Level 4



Level 5



CHARACTER CORRELATION

Disable



Enable



INTERDIGIT RATIO

Accept Any Interdigit Ratio



Set Interdigit Ratio



See page 132



QUIET ZONES

Quiet Zone on One Side



Quiet Zones on Two Sides



Auto



Virtual Quiet Zones on Two Sides



Small Quiet Zones on Two Sides



STITCHING

Disable



Enable





CODE SELECTION

CODE 128

Disable



Enable



GS1-128 ENABLE

**Enable GS1-128 (Transmit Labels
in Code 128 Data Format)**



**Enable GS1-128 (Transmit Labels
in GS1-128 Data Format)**



Disable GS1-128



CODE LENGTH CONTROL

Variable



Fixed



SET LENGTH

**Set Length 1
(or Minimum Length)**



See page 134



See page 135

**Set Length 2
(or Maximum Length)**



CODE SELECTION

Enter/Exit Configuration



EXPAND TO CODE 39

Disable



Enable



Code 128 Check Options

CHECK TX

Disable



Enable



FUNCTION CHARACTER TX

Disable



Enable



SUB-CODE CHANGE TX

Disable



Enable





CODE SELECTION

Code 128 Decoding Options

MINIMUM READS

One Read



Two Reads



Three Reads



Four Reads



DECODING LEVEL

Disable



Level 1



Level 2



Level 3



Level 4



Level 5





CHARACTER CORRELATION

Disable



Enable



QUIET ZONES

No Quiet Zones



Quiet Zone on One Side



Quiet Zones on Two Sides



Auto



Virtual Quiet Zones on Two Sides



STITCHING

Disable



Enable





CODE SELECTION

ISBT 128 CONCATENATION

Disable



Enable



CONCATENATION MODE

Static



Dynamic



DYNAMIC CONCATENATION TIMEOUT

Set Timeout



See page 133



INTERLEAVED 2 OF 5

Disable



Enable



CODE LENGTH CONTROL

Variable



Fixed



SET LENGTH

Set Length 1
(or Minimum Length)



See page 134



See page 135

Set Length 2
(or Maximum Length)





CODE SELECTION

Interleaved 2 of 5 Check Options

CHECK CALCULATION

Disable



Enable Standard (Mod 10) Check



Enable German Parcel Check



Enable DHL Check



Enable Daimler Chrysler Check



Enable Bosch Check



Enable Italian Post Check



CHECK TX

Disable



Enable





Interleaved 2 of 5 Decoding Options

MINIMUM READS

One Read



Two Reads



Three Reads



Four Reads



DECODING LEVEL

Disable



Level 1



Level 2



Level 3



Level 4



Level 5





CODE SELECTION

CHARACTER CORRELATION

Disable



Enable



STITCHING

Disable



Enable



ZERO PATTERN

Disable



Enable





STANDARD 2 OF 5

Disable



Enable



CODE LENGTH CONTROL

Variable



Fixed



SET LENGTH

Set Length 1
(or Minimum Length)



See page 134



See page 135

Set Length 2
(or Maximum Length)



Standard 2 of 5 Check Options

CHECK CALCULATION

Disable



Enable





CODE SELECTION

CHECK TX

Disable



Enable



Standard 2 of 5 Decoding Options

MINIMUM READS

One Read



Two Reads



Three Reads



Four Reads





DECODING LEVEL

Disable



Level 1



Level 2



Level 3



Level 4



Level 5



CHARACTER CORRELATION

Disable



Enable



STITCHING

Disable



Enable





CODE SELECTION

CODABAR

Disable



Enable



CODE LENGTH CONTROL

Variable



Fixed



SET LENGTH

**Set Length 1
(or Minimum Length)**



See page 134



See page 135

**Set Length 2
(or Maximum Length)**



CODE SELECTION

Enter/Exit Configuration



CODABAR ABC

Disable



Enable



CONCATENATION MODE

Static



Dynamic



DYNAMIC CONCATENATION TIMEOUT

Set Timeout



See page 133



CODE SELECTION

Codabar Check Options

CHECK CALCULATION

Disable



Enable AIM Standard Check



Enable Mod-10 Check



CHECK TX

Disable



Enable



START/STOP SET

ABCD/TN*E



ABCD/ABCD



abcd/tn*e



abcd/abcd



CODE SELECTION

Enter/Exit Configuration



START/STOP TX

Disable



Enable



START/STOP MATCH

Disable



Enable



Codabar Decoding Options

MINIMUM READS

One Read



Two Reads



Three Reads



Four Reads





CODE SELECTION

DECODING LEVEL

Disable



Level 1



Level 2



Level 3



Level 4



Level 5



CHARACTER CORRELATION

Disable



Enable



INTERDIGIT RATIO

Accept Any Interdigit Ratio



Set Interdigit Ratio



See page 132



QUIET ZONES

Quiet Zone on One Side



Quiet Zones on Two Sides



Auto



Virtual Quiet Zones on Two Sides



Small Quiet Zones on Two Sides



STITCHING

Disable



Enable





CODE SELECTION

CODE 11

Disable



Enable



CODE LENGTH CONTROL

Variable



Fixed



SET LENGTH

**Set Length 1
(or Minimum Length)**



See page 134



See page 135

**Set Length 2
(or Maximum Length)**





Code 11 Check Options

CHECK CALCULATION

Disable



Enable Check C



Enable Check K



Enable Check C and K



CHECK TX

Disable



Enable





CODE SELECTION

Code 11 Decoding Options

MINIMUM READS

One Read



Two Reads



Three Reads



Four Reads



DECODING LEVEL

Disable



Level 1



Level 2



Level 3



Level 4



Level 5





CHARACTER CORRELATION

Disable



Enable



INTERDIGIT RATIO

Accept Any Interdigit Ratio



See page 132

Set Interdigit Ratio



STITCHING

Disable



Enable





CODE SELECTION

GS1 DATABar OMNIDIRECTIONAL**Disable****Enable**

GS1 DATABar OMNIDIRECTIONAL GS1-128 EMULATION**Disable****Enable**

MINIMUM READS**One Read****Two Reads****Three Reads****Four Reads**



GS1 DATABar EXPANDED

Disable



Enable



GS1 DATABar EXPANDED GS1-128 EMULATION

Disable



Enable



CODE LENGTH CONTROL

Variable



Fixed



SET LENGTH

**Set Length 1
(or Minimum Length)**



See page 134



See page 135

**Set Length 2
(or Maximum Length)**





CODE SELECTION

GS1 DataBar Expanded Decoding Options

MINIMUM READS

One Read



Two Reads



Three Reads



Four Reads



COUPON CONTROL

**Allow All Coupon Barcodes to be
Decoded**



**Enable Only UPC-A Coupon
Decoding**



**Enable Only GS1 Databar Coupon
Decoding**





GS1 DATABAR LIMITED

Disable



Enable



GS1 DATABAR LIMITED GS1-128 EMULATION

Disable



Enable



MINIMUM READS

One Read



Two Reads



Three Reads



Four Reads





CODE SELECTION

CODE 93

Disable



Enable



CODE LENGTH CONTROL

Variable



Fixed



SET LENGTH

**Set Length 1
(or Minimum Length)**



See page 134



See page 135

**Set Length 2
(or Maximum Length)**



CODE SELECTION

Enter/Exit Configuration



Code 93 Check Options

CHECK CALCULATION

Disable



Enable Check C



Enable Check K



Enable Check C and K



CHECK TX

Disable



Enable





CODE SELECTION

Code 93 Decoding Options

MINIMUM READS

One Read



Two Reads



Three Reads



Four Reads



DECODING LEVEL

Disable



Level 1



Level 2



Level 3



Level 4



Level 5





CHARACTER CORRELATION**Disable****Enable**

QUIET ZONES**No Quiet Zones****Quiet Zone on One Side****Quiet Zones on Two Sides****Auto****Virtual Quiet Zones on Two Sides**

STITCHING**Disable****Enable**



CODE SELECTION

MSI

Disable



Enable



CODE LENGTH CONTROL

Variable



Fixed



SET LENGTH

**Set Length 1
(or Minimum Length)**



See page 134



See page 135

**Set Length 2
(or Maximum Length)**



CODE SELECTION

Enter/Exit Configuration



MSI Check Options

CHECK CALCULATION

Disable



Enable Mod 10 Check



Enable Mod 11/10 Check



Enable Mod 10/10 Check



CHECK TX

Disable



Enable





CODE SELECTION

MSI Decoding Options

MINIMUM READS

One Read



Two Reads



Three Reads



Four Reads



DECODING LEVEL

Disable



Level 1



Level 2



Level 3



Level 4



Level 5





STITCHING

Disable



Enable



5 PARAMETER REFERENCES

5.1 RS232 PARAMETERS

This section contains explanations and examples of selected barcode features. See the Configuration section for the actual barcode labels used to configure the reader.

5.1.1 RS232 Only

Baud Rate

Baud rate is the number of bits of data transmitted per second. Set the reader's baud rate to match the baud rate setting of the host device. With an improper baud rate setting, data may not reach the host correctly.

Stop Bits

The stop bit(s) at the end of each transmitted character marks the end of transmission of one character and prepares the receiving device for the next character in the serial data stream. The number of stop bits selected (one or two) depends on the number the receiving terminal is programmed to accommodate. Set the number of stop bits to match host device requirements.

Parity

This feature specifies parity required for sending and receiving data. A parity check bit is the most significant bit of each ASCII coded character. Select the parity type according to host device requirements.

- Select None when no parity bit is required.
- Select Odd parity and the parity bit value is set to 0 or 1, based on data, to ensure that an odd number of 1 bits are contained in the coded character.
- Select Even parity and the parity bit value is set to 0 or 1, based on data, to ensure that an even number of 1 bits are contained in the coded character.

5.1.2 RS232/USB COM Parameters

Intercharacter Delay

This parameter specifies the intercharacter delay between the end of one character and the beginning of the next. The delay can be set within a range of zero (0) to 990 milliseconds in 10 ms increments. A setting of zero specifies no delay.

To set the delay:

1. Determine the desired setting in milliseconds (x 10 ms). (0-99).
2. Use the Chart in [Appendix C](#) to find the hex equivalent for the desired numeric value.
3. Go to [page 39](#) and scan the ENTER/EXIT PROGRAMMING MODE barcode to enter Programming Mode.
4. Scan the barcode: SELECT INTERCHARACTER DELAY.
5. Scan the two hex equivalent characters from the keypad in [Appendix B](#) that represent the numeric value determined in step 1 above.

**NOTE**

If you make a mistake before the last character, scan the CANCEL barcode to abort and not save the entry string. You can then start again at the beginning.

6. Scan the ENTER/EXIT PROGRAMMING MODE barcode to exit.

This completes the procedure.

Disable Character

Specifies the value of the RS232 host command used to disable the reader. Selections: a character from NUL (0x00) to DEL (0x7F).

**NOTE**

The Enable Character must be different from the Disable Character and must not contain reserved characters (see [Appendix D](#)). Setting to previously defined characters such as XON, XOFF, or host commands conflicts with normal operation of these characters. 8-bit data is not recognized when the option Data Bits has been set as 7 Data Bits.

To set the value:

1. Determine the desired character. A setting of 0xFF indicates the Disable Character is not used (not available).
2. Use the Chart in [Appendix C](#) to find the hex equivalent for the desired character.
3. Go to [page 39](#) and scan the ENTER/EXIT PROGRAMMING MODE barcode to enter Programming Mode.
4. Scan the barcode: SELECT DEVICE DISABLE CHARACTER.
5. Scan the two hex equivalent characters from the keypad in [Appendix B](#) that represent the desired character in step 1 above.
6. Scan the ENTER/EXIT PROGRAMMING MODE barcode to exit Programming Mode.

This completes the procedure.

Enable Character

Specifies the value of the RS232 host command used to enable the reader. Selections: a character from NUL (0x00) to DEL (0x7F).



NOTE

The Enable Character must be different from the Disable Character and must not contain reserved characters (see [Appendix D](#)). Setting to previously defined characters such as XON, XOFF, or host commands conflicts with normal operation of these characters. 8-bit data is not recognized when the option Data Bits has been set as 7 Data Bits.

To set this feature:

1. Determine the desired character. A setting of 0xFF indicates the Enable Character is not used (not available).
2. Use the Chart in [Appendix C](#) to find the hex equivalent for the desired character.
3. Go to [page 39](#) and scan the ENTER/EXIT PROGRAMMING MODE barcode to enter Programming Mode.
4. Scan the barcode: SELECT DEVICE ENABLE CHARACTER.
5. Scan the two hex equivalent characters from the keypad in [Appendix B](#) that represent the desired character in step 1 above.
6. Scan the ENTER/EXIT PROGRAMMING MODE barcode to exit Programming Mode.

This completes the procedure.

ACK NAK Options

This enables/disables the ability of the reader to support the RS232 ACK/NAK protocol. When configured, the reader and/or host sends an “ACK” when it receives data properly, and sends “NAK” when the data is in error.

Options are:

- Disable
- Enable for label transmission — The reader expects an ACK/NAK response from the host when a label is sent.
- Enable for host-command acknowledge — The reader will respond with ACK/NAK when the host sends a command.
- Enable for label transmission and host-command acknowledge

ACK Character

This setting specifies an ASCII character to be used as the ACK character. Selections: a character from NUL (0x00) to DEL (0x7F).



NOTE

The ACK Character must be different from the NAK Character and must not contain reserved characters (see [Appendix D](#)). Setting to previously defined characters such as XON, XOFF, or host commands conflicts with normal operation of these characters. 8-bit data is not recognized when the option Data Bits has been set as 7 Data Bits.

To set this feature:

1. Determine the desired character.
2. Use the Chart in [Appendix C](#) to find the hex equivalent for the desired character.
3. Go to [page 39](#) and scan the ENTER/EXIT PROGRAMMING MODE to enter Programming Mode.
4. Scan the barcode: SELECT ACK CHARACTER.
5. Scan the two hex equivalent characters from the keypad in [Appendix B](#) that represent the desired character in step 1 above.
6. Scan the ENTER/EXIT PROGRAMMING MODE barcode to exit Programming Mode.

This completes the procedure.

NAK Character

This setting specifies an ASCII character to be used as the NAK character. Selections: a character from NUL (0x00) to DEL (0x7F).



NOTE

The ACK Character must be different from the NAK Character and must not contain reserved characters (see [Appendix D](#)). Setting to previously defined characters such as XON, XOFF, or host commands conflicts with normal operation of these characters. 8-bit data is not recognized when the option Data Bits has been set as 7 Data Bits.

To set this feature:

1. Determine the desired character.
2. Use the Chart in [Appendix C](#) to find the hex equivalent for the desired character.
3. Go to [page 40](#) and scan the ENTER/EXIT PROGRAMMING MODE barcode to enter Programming Mode.
4. Scan the barcode: SELECT NAK CHARACTER.
5. Scan the two hex equivalent characters from the keypad in [Appendix B](#) that represent the desired character in step 1 above.
6. Scan the ENTER/EXIT PROGRAMMING MODE barcode to exit Programming Mode.

This completes the procedure.

ACK NAK Timeout Value

This option specifies the amount of time the reader waits for an ACK character from the host following label transmission. The selectable timeout range is 200 ms to 15,000 ms (15 seconds) in 200 ms increments. A selection of 0 disables the timeout.

To set this value:

1. Determine the desired setting in milliseconds (x 200 ms). (0-75).
2. Use the Chart in [Appendix C](#) to find the hex equivalent for the desired numeric value.
3. Go to [page 40](#) and scan the ENTER/EXIT PROGRAMMING MODE barcode to enter Programming Mode.
4. Scan the barcode: SELECT ACK NAK TIMEOUT VALUE.
5. Scan the two hex equivalent characters from the keypad in [Appendix B](#) that represent the numeric value determined in step 1 above.

**NOTE**

If you make a mistake before the last character, scan the CANCEL barcode to abort and not save the entry string. You can then start again at the beginning.

6. Scan the ENTER/EXIT PROGRAMMING MODE barcode to exit Programming Mode.

This completes the procedure.

ACK NAK Retry Count

This feature specifies the number of times the reader retries a label transmission due to a retry condition. The selectable range is from 1 to 254 retries. A selection of 0 disables the count (no retries), and a selection of 255 specifies unlimited retries.

To set this feature:

1. Determine the desired number of retries. (0-255).
2. Use the Chart in [Appendix C](#) to find the hex equivalent for the desired numeric value.
3. Go to [page 40](#) and scan the ENTER/EXIT PROGRAMMING MODE barcode to enter Programming Mode.
4. Scan the barcode: SELECT ACK NAK RETRY COUNT.
5. Scan the two hex equivalent characters from the keypad in [Appendix B](#) that represent the numeric value determined in step 1 above.

**NOTE**

If you make a mistake before the last character, scan the CANCEL barcode to abort and not save the entry string. You can then start again at the beginning.

6. Scan the ENTER/EXIT PROGRAMMING MODE barcode to exit Programming Mode.

This completes the procedure.

Keyboard Intercode Delay

This parameter specifies the intercode delay between the end of one code and the beginning of the next. The delay can be set within a range of zero (0) to 99 seconds in 1 second increments. A setting of zero specifies no delay.

To set the delay:

1. Determine the desired setting in seconds. (0-99).
2. Use the Chart in [Appendix C](#) to find the hex equivalent for the desired numeric value.
3. Go to [page 43](#) and scan the ENTER/EXIT PROGRAMMING MODE barcode to enter Programming Mode.
4. Scan the barcode: SELECT INTERCODE DELAY.
5. Scan the two hex equivalent characters from the keypad in [Appendix B](#) that represent the numeric value determined in step 1 above.



NOTE

If you make a mistake before the last character, scan the CANCEL barcode to abort and not save the entry string. You can then start again at the beginning.

6. Scan the ENTER/EXIT PROGRAMMING MODE barcode to exit.

This completes the procedure.

5.2 READING PARAMETERS

5.2.1 Illumination Mode

Illumination Mode

Selects the illumination mode for the reader. The illumination mode can be used to:

- to increase the overall diode life
- to reduce power consumption;
- to turn off the illuminator for safety purposes.

Selections:

Disabled: the illuminator is always off.

Enabled: the illuminator is always on.

Triggered: the illuminator is turned on when the reading phase starts. The illuminator is turned off as soon as the code(s) are read or when the reading phase ends.



NOTE

The Triggered selection is ignored for Automatic and Test Operating Modes.

5.2.2 Operating Mode

Operating Mode

Selects the scan operating mode for the reader. Selections:

On Line: the reading phase is defined as the time between the Phase ON and Phase OFF events. The Phase events can be signals coming from the trigger button (or external presence sensor connected to the scanner input for RS232 models).

Serial On Line: the reading phase is defined as the time between the Phase ON and Phase OFF events. The Phase events are serial start/stop strings sent from the host over the serial interface.

Automatic: The device does not require connections with external presence sensors in this operating mode. In this mode the scanner is continuously scanning. The reading phase is enabled when a barcode enters the reading zone of the scanner and is terminated after an N number of scans without a code, where N is set using the Automatic Threshold selection. The next reading phase will begin when a code enters the reading zone of the scanner again. The N number of scans without a code must be selected to assure code identification in the reading zone. Code transmission is identical to the other operating modes except that there is no transmission on the serial port in the case of a No Read condition.

Automatic (Object Sense): The reader is normally in the Object Sense state (a low power/ready-to-read condition). When an item is automatically detected in the reader's field of view, the Automatic operating mode is turned on. The Automatic Threshold assures code identification. When objects are no longer present in the reading field, the Timeout ends Automatic mode and returns the reader to the Object Sense state.

Test: The Test mode reports information about the reading performance of the scanner and the code is continuously read. After 100 scans, the following information is transmitted on the serial interface:

- the code content
- percentage of good reads (if the good read percentage is 0 no transmission is done)

The information can be displayed on the Host PC by running a terminal emulator program (ex. Hyper Terminal). The output data format is fixed.

Automatic Threshold

For Automatic operating modes, the Automatic Threshold sets an N number of scans without a code in order to assure code identification in the reading zone. Selection: a value from 2 to 255.

To set this value:

1. Determine the desired number of reads. (2-255).
2. Use the Chart in [Appendix C](#) to find the hex equivalent for the desired numeric value.
3. Go to [page 47](#) and scan the ENTER/EXIT PROGRAMMING MODE barcode to enter Programming Mode.
4. Scan the barcode: SELECT AUTOMATIC THRESHOLD VALUE.

5. Scan the two hex equivalent characters from the keypad in [Appendix B](#) that represent the numeric value determined in step 1 above.

**NOTE**

If you make a mistake before the last character, scan the CANCEL barcode to abort and not save the entry string. You can then start again at the beginning.

6. Scan the ENTER/EXIT PROGRAMMING MODE barcode to exit Programming Mode.

This completes the procedure.

Phase Off Event

This parameter determines how the reading phase is concluded for On Line and Serial On Line modes:

Trigger Stop: the reading phase ends only when a Stop Input or Serial Stop String is received; the Timeout is disabled.

Timeout: the reading phase ends only when the Timeout expires; Stop Input or Serial Stop Strings are ignored.

Trigger Stop-Timeout: the Stop Input or Serial Stop Strings define the end of the reading phase. If no Stop Input or Serial Stop String is received then the Timeout ends the reading phase.

Timeout

Determines the Timeout for a Phase Off Event or Automatic Object Sense state as follows.

For On Line and Serial On Line modes, it defines a timeout which determines the maximum length of the reading phase depending on the Phase Off Event selection.

For Automatic (Object Sense) mode, it defines a timeout which allows the reader to return to the Object Sense state after objects are no longer present in the reading field.

Selections: from 40 to 5100 ms in 20 ms increments.

To set this value:

1. Determine the desired setting in milliseconds (x 20 ms). (2-255).
2. Use the Chart in [Appendix C](#) to find the hex equivalent for the desired numeric value.
3. Go to [page 48](#) and scan the ENTER/EXIT PROGRAMMING MODE barcode to enter Programming Mode.
4. Scan the barcode: SELECT TIMEOUT VALUE.
5. Scan the two hex equivalent characters from the keypad in [Appendix B](#) that represent the numeric value determined in step 1 above.

**NOTE**

If you make a mistake before the last character, scan the CANCEL barcode to abort and not save the entry string. You can then start again at the beginning.

6. Scan the ENTER/EXIT PROGRAMMING MODE barcode to exit Programming Mode.

This completes the procedure.

Serial Start

The Serial Start string (max 20 characters), signals the beginning of the reading phase. Selections: characters from NUL (0x00) to ~ (0x7E).



NOTE

The ACK Character must be different from the NAK Character and must not contain reserved characters (see [Appendix D](#)). Setting to previously defined characters such as XON, XOFF, or host commands conflicts with normal operation of these characters. 8-bit data is not recognized when the option Data Bits has been set as 7 Data Bits.

To set this feature:

1. Determine the desired character string (max 20).
2. Use the Chart in [Appendix C](#) to find the hex equivalent(s) for the desired character(s).
3. Go to [page 48](#) and scan ENTER/EXIT PROGRAMMING MODE to enter Programming Mode.
4. Scan the barcode: SELECT SERIAL START CHARACTERS.
5. Scan the hex equivalent characters from the keypad in [Appendix B](#) that represent the desired character string in step 1 above.
6. If less than the expected string of 20 characters are selected, scan the ENTER/EXIT barcode to terminate the string.
7. Scan the ENTER/EXIT PROGRAMMING MODE barcode to exit Programming Mode.

This completes the procedure.

Serial Stop

The Serial Stop string (max 20 characters), signals the end of the reading phase. Selections: characters from NUL (0x00) to ~ (0x7E).



NOTE

The ACK Character must be different from the NAK Character and must not contain reserved characters (see [Appendix D](#)). Setting to previously defined characters such as XON, XOFF, or host commands conflicts with normal operation of these characters. 8-bit data is not recognized when the option Data Bits has been set as 7 Data Bits.

To set this feature:

1. Determine the desired character string (max 20).
2. Use the Chart in [Appendix C](#) to find the hex equivalent(s) for the desired character(s).
3. Go to [page 48](#) and scan ENTER/EXIT PROGRAMMING MODE to enter Programming Mode.
4. Scan the barcode: SELECT SERIAL STOP CHARACTERS.
5. Scan the hex equivalent characters from the keypad in [Appendix B](#) that represent the desired character string in step 1 above.

6. If less than the expected string of 20 characters are selected, scan the ENTER/EXIT barcode to terminate the string.
7. Scan the ENTER/EXIT PROGRAMMING MODE barcode to exit Programming Mode.

This completes the procedure.

5.2.3 Good Read LED

LED Indication

Specifies when the scanner will provide indication upon successfully reading a barcode. Selections:

On Decode = Indicate Good Read immediately after decoding.

After Transmission = Indicate Good Read after code transmission towards host.

5.3 DATA FORMATTING

When a barcode is scanned, additional information can be sent to the host computer along with the barcode data. This combination of barcode data and supplementary user-defined data is called a “message string.” The Data Editing features can be used to build specific user-defined data into a message string.

There are several types of selectable data characters that can be sent before and after scanned data. You can specify if they should be sent with all symbologies, or only with specific symbologies. The figure below shows the available elements you can add to a message string:




Figure 6 - Breakdown of a Message String



NOTE

Additional advanced formatting is available. See the Advanced Formatting features in the Datalogic Aladdin™ configuration software.

Please Keep In Mind...

- Modifying a message string is not a mandatory requirement. Data editing is a sophisticated feature allowing highly customizable output for advanced users. Factory default settings for data editing is typically set to NONE.
- A prefix (header) or suffix (terminator) may be applied to all messages (set via the [Global Prefix/Suffix](#) feature).
- [Label ID: Pre-loaded Set](#) can be applied to all symbologies, as well as customizing specific Label IDs (set via the [Label ID: Set Individually Per Symbology](#) feature).
- You can add any character from the ASCII Chart (from 0x00 - 0xFF) in [Appendix C](#) as a Prefix, Suffix or Custom Label ID.
- Enter prefixes and suffixes in the order in which you want them to appear in the output.

5.3.1 Global Prefix/Suffix

Up to 20 ASCII characters may be added as a prefix (header) in a position before the barcode data, and/or as a suffix (terminator) in a position following the barcode data as indicated in the figure below.




Figure 7 - Prefix and Suffix Positions

Example: Setting a Prefix

In this example, we'll set a prefix for all symbologies.

1. Determine which ASCII character(s) are to be added to scanned barcode data (max 20). In this example, we'll add a dollar sign ('\$') as a prefix.
2. Use the Chart in [Appendix C](#) to find the hex equivalent(s) for the desired character(s).
3. Go to [page 52](#) and scan the ENTER/EXIT PROGRAMMING MODE barcode to enter Programming Mode.
4. Scan the SET GLOBAL PREFIX barcode.
5. Scan the hex equivalent characters from the keypad in [Appendix B](#) that represent the desired character string in step 1 above. The corresponding hex number for the '\$' character is 24. To enter this selection code, scan the '2' and '4' barcodes from [Appendix B](#).



NOTE

If you make a mistake before the last character, scan the CANCEL barcode to abort and not save the entry string. You can then start again at the beginning.

6. If less than the expected string of 20 characters are selected, scan the ENTER/EXIT barcode to terminate the string.
7. Scan the ENTER/EXIT barcode once again to exit Programming Mode.

The resulting message string would appear as follows:

Scanned barcode data: **12345**

Resulting message string output: **\$12345**

No Read String

This defines the string to be displayed in case of No Read (On Line Mode only).

To set this feature:

1. Determine the desired character string (max 20).
2. Use the Chart in [Appendix C](#) to find the hex equivalent(s) for the desired character(s).
3. Go to [page 52](#) and scan ENTER/EXIT PROGRAMMING MODE to enter Programming Mode.
4. Scan the barcode: SELECT NO READ STRING.
5. Scan the hex equivalent characters from the keypad in [Appendix B](#) that represent the desired character string in step 1 above.
6. If less than the expected string of 20 characters are selected, scan the ENTER/EXIT barcode to terminate the string.
7. Scan the ENTER/EXIT PROGRAMMING MODE barcode to exit Programming Mode.

This completes the procedure.

5.3.2 Code Identifiers

Label IDs

A Label ID is a customizable code of up to three ASCII characters (each can be from 0x00 - 0xFF), used to identify a barcode (symbology) type. It can be appended previous to or following the transmitted barcode data depending upon how this option is enabled. This feature provides options for configuring custom Label IDs as a pre-loaded set (see "Label ID: Pre-loaded Set") or individually per symbology (see "Label ID: Set Individually Per Symbology").

If you wish to program the reader to always include an industry standard label identifier for ALL symbology types, see "Global AIM ID" on [page 128](#).

Label ID: Pre-loaded Set

The reader supports a pre-loaded set of Label IDs. The following table shows this set.

BARCODE SYMBOLOGY	Factory Label ID Set	Custom
EAN 8	A	
EAN 8 with 2 Add On	J	
EAN 8 with 5 Add On	K	
EAN 13	B	
EAN 13 with 2 Add On	L	
EAN 13 with 5 Add On	M	
UPC A	C	
UPC A with 2 Add On	F	
UPC A with 5 Add On	G	
UPC E	D	
UPC E with 2 Add On	H	
UPC E with 5 Add On	I	
GTIN	\$A	
GTIN with 2 Add On	\$B	
GTIN with 5 Add On	\$C	
Code 39	V	
Code 32	X	
Code 128	T	
GS1-128	k	
ISBN	@	
ISSN	n	
ISBT 128	f	
Interleaved 2 of 5	N	
Standard 2 of 5	P	
Codabar	R	
ABC Codabar	S	
Code 11	b	
GS1 Databar Omnidirectional	u	
GS1 Databar Expanded	t	
GS1 Databar Limited	v	
Code 93	U	
MSI	Z	

Label ID: Set Individually Per Symbology

To configure a Label ID individually for a single symbology:

1. Go to [page 53](#) and scan the ENTER/EXIT barcode.
2. Select Label ID position as either BEFORE (Enable as Prefix) or AFTER (Enable as suffix) by scanning the appropriate barcode in the section "[Transmit Custom Label IDs](#)" on [page 53](#). Reference the figure below for Label ID positioning options.
3. Scan a barcode to select the symbology for which you wish to configure a custom Label ID from the section "[Custom Label Identifiers](#)" starting on [page 53](#).
4. Determine the desired character(s) (max 3) which will represent the Label ID for the selected symbology.
5. Use the Chart in [Appendix C](#) to find the hex equivalent(s) for the desired character(s).
6. Scan the hex equivalent characters from the keypad in [Appendix B](#) that represent the desired character string in step 4 above. If you wish to select an equal sign, the corresponding hex number for the '=' character is 3D. To enter this selection code, scan the '3' and 'D' barcodes from [Appendix B](#).



NOTE

If you make a mistake before the last character, scan the CANCEL barcode to abort and not save the entry string. You can then start again at the beginning.

7. If less than the expected string of 3 characters are selected, scan the ENTER/EXIT barcode to terminate the string.
8. Scan the ENTER/EXIT barcode once again to exit Programming Mode.

This completes the steps to configure a Label ID for a given symbology.




Figure 8 - Label ID Position Options

Global AIM ID



NOTE

This feature enables/disables addition of AIM IDs for all symbology types.

AIM label identifiers (as opposed to custom Label IDs you select yourself) can be included with scanned barcode data. AIM label identifiers consist of three characters as follows:

- A close brace character (ASCII '['), followed by...
- A code character (see the table below), followed by...
- A modifier character (the modifier character is symbol dependent).




Figure 9 - AIM ID

AIM STANDARD IDENTIFIER TABLE			
BARCODE SYMBOLOGY	AIM STANDARD	BARCODE SYMBOLOGY	AIM STANDARD
EAN 8] E 4	Code 39] A y
EAN 8 with 2 Add On] E 5	Code 32] X y
EAN 8 with 5 Add On] E 6	Code 128] C y
EAN 8 with GS1-128 Add On		GS1-128] C y
EAN 13] E 0	ISBN] C4
EAN 13 with 2 Add On] E 1	ISSN] C4
EAN 13 with 5 Add On] E 2	ISBT 128] C4
EAN 13 with GS1-128 Add On		Interleaved 2 of 5] I y
UPC A] X y	Standard 2 of 5] S y
UPC A with 2 Add On] X y	Codabar] F y
UPC A with 5 Add On] X y	ABC Codabar] X y
UPC-A with GS1-128 Add On		Code 11] G y
UPC E] X y	GS1 Databar Omnidirectional] e y
UPC E with 2 Add On] X y	GS1 Databar Expanded] e y
UPC E with 5 Add On] X y	GS1 Databar Limited] e y
UPC-E with GS1-128 Add On		Code 93] G y
GTIN] E 0	MSI] M y
GTIN with 2 Add On] E 5		
GTIN with 5 Add On] E 6		
GTIN with GS1-128 Add On] E 2		

AIM standard identifiers are not defined for all codes: the X identifier is assigned to the code for which the standard is not defined. The y value depends on the selected options (check digit calculated or not, check digit tx or not, etc.).

5.3.3 Code Verifier

Match String

This is the string used as the match code for code verification. The Match String must be configured to include start/stop characters and check digits if their transmission is enabled.

It is possible to define the Match string by inserting:

- all printable characters
- non printable ASCII characters
- No wild card characters are supported

To set this feature:

1. Determine the desired character string (max 32).
2. Use the Chart in [Appendix C](#) to find the hex equivalent(s) for the desired character(s).
3. Go to [page 51](#) and scan ENTER/EXIT PROGRAMMING MODE to enter Programming Mode.
4. Scan the barcode: SELECT MATCH STRING.
5. Scan the hex equivalent characters from the keypad in [Appendix B](#) that represent the desired character string in step 1 above.
6. If less than the expected string of 32 characters are selected, scan the ENTER/EXIT barcode to terminate the string.
7. Scan the ENTER/EXIT PROGRAMMING MODE barcode to exit Programming Mode.

This completes the procedure.

Wrong Code String

This is the string sent in case of a mismatch (wrong code read).

To set this feature:

1. Determine the desired character string (max 20).
2. Use the Chart in [Appendix C](#) to find the hex equivalent(s) for the desired character(s).
3. Go to [page 51](#) and scan ENTER/EXIT PROGRAMMING MODE to enter Programming Mode.
4. Scan the barcode: SELECT WRONG CODE STRING.
5. Scan the hex equivalent characters from the keypad in [Appendix B](#) that represent the desired character string in step 1 above.
6. If less than the expected string of 20 characters are selected, scan the ENTER/EXIT barcode to terminate the string.
7. Scan the ENTER/EXIT PROGRAMMING MODE barcode to exit Programming Mode.

This completes the procedure.

5.4 DIGITAL OUTPUTS

Activation Event

Defines the event activating the output.

Selections:

Disabled: the output is always in the selected idle state.

Good Read: the event occurs if the code is read.

No Read: the event occurs if no code is read.

Wrong Code: the event occurs if a code is successfully decoded but does not match the Verifier Code.

Deactivation Event

Defines the event deactivating the output.

Selections:

Timeout: the output deactivation event occurs after the deactivation timeout expires.

Reading Phase Active: the output deactivation event occurs, when a start reading phase event takes place.

Disabled: No deactivation event occurs.

Deactivation Timeout

When the Deactivation Event is Timeout, this indicates the maximum duration of the output pulse.

Active Level

Determines the active state of the output.

Each output can be represented as an NPN transistor; this transistor acts like a switch: so, when the transistor is OFF, it acts like an OPEN switch. On the contrary, when the transistor is ON, it acts like a CLOSED switch.

Selections:

Active Closed: the idle state of the output line is open, that is, the NPN transistor is OFF (like an open switch). When the output is activated, the transistor goes ON (like a closed switch).

Active Open: the idle state of the output line is closed, that is, the NPN transistor is ON (like a closed switch). When the output is activated, the transistor goes OFF (like an open switch).

5.5 POWER SAVE

Sleep Mode Timeout

Specifies the timeout value for the reader to enter low power Sleep Mode.

This is available only in On Line operating mode.

The reader wakes up when receiving an input signal or trigger button press. The reader cannot connect to Aladdin when in power save mode. It must first receive a wake up from the input signal or trigger button press.

5.6 CODE SELECTION

EAN-UPC Optional Add-On Timer

This option sets the time the reader will look for an add-on when an add-on fragment has been seen and optional add-ons are enabled.

To set this value:

1. Determine the desired setting in milliseconds (x 10 ms). (1-30).
2. Use the Chart in [Appendix C](#) to find the hex equivalent for the desired numeric value.
3. Go to [page 71](#) and scan the ENTER/EXIT PROGRAMMING MODE barcode to enter Programming Mode.
4. Scan the barcode: SET ADD-ON TIMER VALUE.
5. Scan the two hex equivalent characters from the keypad in [Appendix B](#) that represent the numeric value determined in step 1 above.



NOTE

If you make a mistake before the last character, scan the CANCEL barcode to abort and not save the entry string. You can then start again at the beginning.

6. Scan the ENTER/EXIT PROGRAMMING MODE barcode to exit Programming Mode.

This completes the procedure.

Decoding Level

Decoding Levels are used to configure a barcode symbology decoder to be very aggressive to very conservative depending on a particular customer's needs.

- **Level 1** results in a very conservative decoder at the expense of not being able to read poorly printed or damaged labels.
- **Level 5** results in a very aggressive decoder. This aggressive behavior allows decoding of poorly printed and damaged labels at the expense of increasing the likelihood of decoding errors.
- **Level 3**, which is the default setting, allows the majority of product labels to be decoded.

There are many factors that determine when to change the decoding level for a particular symbology. These factors include spots, voids, non-uniform bar/space widths, damaged labels, etc. that may be experienced in some barcode labels. If there are many hard to read or damaged labels that cannot be decoded using a conservative setting, increase the decoding level to be more aggressive. If the majority of labels are very good quality labels, or there is a need to decrease the possibility of a decoder error, lower the decoding level to a more conservative level.

Minimum Reads

This feature specifies the minimum number of consecutive times a label must be decoded before it is accepted as good read.

Interdigit Ratio

This feature specifies the ratio between an intercharacter space and module for given symbology labels.

To set this value:

1. Determine the desired ratio setting. (1-10).
2. Use the Chart in [Appendix C](#) to find the hex equivalent for the desired numeric value.
3. Go to relative Code Symbology page and scan the ENTER/EXIT PROGRAMMING MODE barcode to enter Programming Mode.
4. Scan the barcode: SET INTERDIGIT RATIO.
5. Scan the two hex equivalent characters from the keypad in [Appendix B](#) that represent the numeric value determined in step 1 above.



NOTE

If you make a mistake before the last character, scan the CANCEL barcode to abort and not save the entry string. You can then start again at the beginning.

6. Scan the ENTER/EXIT PROGRAMMING MODE barcode to exit Programming Mode.

This completes the procedure.

Character Correlation

When correlation is enabled, the barcode reader will combine label data from multiple scans when decoding. Enabling correlation will help the scanner read labels that have some spots and/or voids. It may also help read labels that have damaged areas. Enabling correlation will also increase the chances that a label will be read incorrectly.

Stitching

This option enables/disables stitching for given symbology labels. When parts of a barcode are presented to the reader with this feature enabled, the barcode parts will be assembled by the reader's software, and the data will be decoded if all barcode proofing requirements are met.

Quiet Zones

This feature specifies the number of quiet zones for given symbology labels. Quiet zones are blank areas at the ends of a barcode and are typically 10 times the width of the narrowest bar or space in the label.

5.6.1 Concatenation

Concatenation Mode

Specifies the concatenation mode between Static and Dynamic. Static requires the concatenated codes to be read in the same scan (simultaneously). Dynamic allows the two codes to be read separately (within the specified Dynamic Concatenation Timeout).

Dynamic Concatenation Timeout

Specifies the timeout in 10-millisecond ticks used by the Dynamic Concatenation Mode.

To set this value:

1. Determine the desired setting in milliseconds (x 10 ms). (5-255).
2. Use the Chart in [Appendix C](#) to find the hex equivalent for the desired numeric value.
3. Go to relative Dynamic Concatenation Timeout page and scan the ENTER/EXIT PROGRAMMING MODE barcode to enter Programming Mode.
4. Scan the barcode: SET TIMEOUT.
5. Scan the two hex equivalent characters from the keypad in [Appendix B](#) that represent the numeric value determined in step 1 above.



If you make a mistake before the last character, scan the CANCEL barcode to abort and not save the entry string. You can then start again at the beginning.

6. Scan the ENTER/EXIT PROGRAMMING MODE barcode to exit Programming Mode.

This completes the procedure.

5.6.2 Set Length

Length Control allows you to select either variable length decoding or fixed length decoding for the specified symbology.

- **Variable Length:** any length between a minimum and maximum length (inclusive).
- **Fixed Length:** one or two different fixed lengths

Set Length 1

This feature specifies one of the barcode lengths for Length Control. Length 1 is the minimum label length if in Variable Length Mode, or the first fixed length if in Fixed Length Mode.

The length that can be set varies, depending on the symbology, however Length 1 cannot be 0. Reference the page for your selected symbology to see specific variables.



NOTE

Code 39, Code 128, I 2/5, S 2/5, Code 11, Code 93, MSI

The specified length includes the check character (if any), data and ASCII shift characters. It does not include the start/stop characters.



NOTE

Codabar

The specified length includes the check character (if any), data and the start/stop characters.

Follow these instructions to set this feature:

1. Determine the desired character length (varies depending on symbology).
2. Use the Chart in [Appendix C](#) to find the hex equivalent(s) for the desired numeric value.
3. Go to the Set Length page for your selected symbology and scan the ENTER/EXIT PROGRAMMING MODE barcode to enter Programming Mode.
4. Scan the barcode to SELECT LENGTH 1 SETTING for your selected symbology.
5. Scan the two hex equivalent characters from the keypad in [Appendix B](#) that represent the numeric value determined in step 1 above.



NOTE

If you make a mistake before the last character, scan the CANCEL barcode to abort and not save the entry string. You can then start again at the beginning.

6. Scan the ENTER/EXIT PROGRAMMING MODE barcode to exit Programming Mode.

This completes the procedure.

Set Length 2

This feature specifies one of the barcode lengths for Length Control. Length 2 is the maximum label length if in Variable Length Mode, or the second fixed length if in Fixed Length Mode.

The length that can be set varies depending on the symbology. For Fixed Length Mode, a setting of 0 specifies to ignore Length 2 (use only Length 1). Reference the page for your selected symbology to see specific variables.

**NOTE****Code 39, Code 128, I 2/5, S 2/5, Code 11, Code 93, MSI**

The specified length includes the check character (if any), data and ASCII shift characters. It does not include the start/stop characters.

**NOTE****Codabar**

The specified length includes the check character (if any), data and the start/stop characters.

Follow these instructions to set this feature:

1. Determine the desired character length (varies depending on symbology).
2. Use the Chart in [Appendix C](#) to find the hex equivalent(s) for the desired numeric value.
3. Go to the Set Length page for your selected symbology and scan the ENTER/EXIT PROGRAMMING MODE barcode to enter Programming Mode.
4. Scan the barcode to SELECT LENGTH 2 SETTING for your selected symbology.
5. Scan the two hex equivalent characters from the keypad in [Appendix B](#) that represent the numeric value determined in step 1 above.

**NOTE**

If you make a mistake before the last character, scan the CANCEL barcode to abort and not save the entry string. You can then start again at the beginning.

6. Scan the ENTER/EXIT PROGRAMMING MODE barcode to exit Programming Mode.


This completes the procedure.

6 TECHNICAL FEATURES

Electrical Features	RS232		USB	
Power supply	5 Vdc ± 5%			
Consumption	350 mA; 1.75 W			
Interfaces	RS232, USB			
Inputs Input 1 (External Trigger), Voltage Current Consumption Minimum Pulse Duration	Optocoupled, polarity insensitive 5 to 30 Vdc 9 mA max. 5 ms			
Outputs Output 1, Output 2 V _{CE} Collector Current V _{CE} Saturation Power Dissipation	Optocoupled 30 Vdc max. 40 mA continuous max.; 130 mA pulsed max. 1V max. at 10 mA 80 mW max. at 45 °C (ambient temperature)			
Reading Features				
Max Scans/sec	320			
Max resolution	0.076 mm (3mils)			
Readable codes:	EAN/UPC, Code 39, Code 32, Code 128, GS1-128, ISBT 128, Interleaved and Standard 2 of 5, Codabar, ABC Codabar, GS1 Databar (Omnidirectional, Limited, Expanded), Code 93, Code 11, MSI			
Physical Features	Scanner		Scan Engine	
	RS232	USB	RS232	USB
Width	57 mm (2.24 inches)		50 mm (1.96 inches)	
Length	50 mm (1.96 inches)		43 mm (1.69 inches)	
Height	31 mm (1.22 inches)		21 mm (0.82 inches)	
Weight - max.	120 g. (4.2 oz.)	105 g. (3.7 oz.)	30 g. (1 oz.)	
Environmental Features				
Operating Temperature ①	0° to +50 °C (+32° to +122 °F)			
Storage Temperature	-20° to +70 °C (-4° to +158 °F)			
Humidity max.	90% non condensing			
Protection Class EN 60529	IP64		-	

6.1 READING DIAGRAMMS

The following diagram was obtained according to the conditions listed below. Code reading with skew angles of less than 10° may cause decreased performance due to direct light reflection.



(0,0) corresponds to the scanner output window.

Conditions:

Code = Code 39
Quality = Grade A
Lighting = No Ambient Light (0 Lux)
Pitch = 0°
Skew = 10°
Tilt = 0°

A DEFAULT PARAMETERS TABLE

Parameter	Default	Your Setting	Page
GLOBAL INTERFACE FEATURES			
Host Commands — Obey/Ignore	Obey		
RS232 ONLY			
Baud Rate	9600		
Data Bits	8 Data Bits		
Stop Bits	1 Stop Bit		
Parity	None		
RS232/USB-COM			
Intercharacter Delay	No Delay		
Disable Character	'D'		
Enable Character	'E'		
ACK NAK Options	Disable		
ACK Character	'ACK'		
NAK Character	'NAK'		
ACK NAK Timeout Value	600 ms		
ACK NAK Retry Count	3 Retries		
ACK NAK Error Handling	Ignore Errors Detected		
USB-KBD			
Keyboard Country Mode	US		
Keyboard Intercode Delay	No Delay		
Send Control Characters	CTRL+KEY		
USB Keyboard Speed	1 ms		
READING PARAMETERS			
Illumination Mode	Triggered		
Operating Modes	On Line		
Phase Off Event	Trigger Stop		
Automatic Threshold			
Timeout			
Serial Start	STX		
Serial Stop	ETX		
LED Indication	On Decode		
Label Programming Mode	Enabled		
DATA FORMAT			
Data Transmission	On Decode		
Code Verifier Mode	Disabled		
Match String			
Wrong Code String			
Case Conversion	Disabled		
Global Prefix (Header)	CR		
Global Suffix (Terminator)			
No Read String	CAN		
Transmit AIM IDs	Disabled		
Transmit Custom Label IDs	Disabled		
Custom Label Identifiers	See table on page 126		

Parameter	Default	Your Setting	Page
DIGITAL OUTPUTS			
OUTPUT 1			
Activation Event	Disabled		
Deactivation Event	Disabled		
Deactivation Timeout	500 ms		
Active Level	Active Closed		
OUTPUT 2			
Activation Event	Disabled		
Deactivation Event	Disabled		
Deactivation Timeout	500 ms		
Active Level	Active Closed		
POWER SAVE			
Sleep Mode Timeout	Disabled		
CODE SELECTION			
UPC-A			
UPC-A	Enable		
Check Character Tx	Enable		
Expand to EAN-13	Disable		
Number System Tx	Enable		
Minimum Reads	One Read		
Coupon Control	Enable only UPC-A		
UPC-E			
UPC-E	Enable		
Check Character Tx	Enable		
Expand to UPC-A	Disable		
Expand to EAN-13	Disable		
Number System Tx	Enable		
Minimum Reads	Two Reads		
EAN-13			
EAN-13	Enable		
Check Character Tx	Enable		
ISBN Conversion	Disable		
ISSN Conversion	Disable		
Flag 1 Character	Enable		
Minimum Reads	One Read		
Coupon Control	Enable only UPC-A		
EAN-8			
EAN-8	Enable		
Check Character Tx	Enable		
Expand to EAN-13	Disable		
Minimum Reads	One Read		
Add-Ons			
P2 Add-On	Disable		
P5 Add-On	Disable		
P2 Minimum Reads			
P5 Minimum Reads			
Optional Add-On Timer	70 ms		

Parameter	Default	Your Setting	Page
CODE SELECTION (continued)			
EAN/UPC Global Settings			
GTIN Format	Disable		
Decoding Level	Level 2		
Character Correlation	Disable		
In-Store Minimum Reads	Two Reads		
Code 39			
Code 39	Enable		
Code 39 Full ASCII	Disable		
Code Length Control	Variable		
Set Length	2 - 50		
Code 32 (Italian Pharma)	Disable		
Code 32 Check Tx			
Code 32 Start/Stop Tx			
Code 39 Check Options			
Check Calculation	Disable		
Code 39 Check Tx	Enable		
Code 39 Start/Stop Tx	Disable		
Code 39 Decoding Options			
Minimum Reads	Two Reads		
Decoding Level	Level 3		
Character Correlation	Disable		
Interdigit Ratio	4		
Quiet Zones	Auto		
Stitching	Enable		
Code 128 (GS1-128)			
Code 128	Enable		
GS1-128 Enable	Enable GS1-128 (Transmit Labels in GS1-128 Data Format)		
Code Length Control	Variable		
Set Length	1 - 80		
Expand to Code 39	Disable		
Check Options			
Check Tx	Disable		
Function Character Tx	Disable		
Sub-Code Change Tx	Disable		
Decoding Options			
Minimum Reads	One Read		
Decoding Level	Level 3		
Character Correlation	Disable		
Quiet Zones	Auto		
Stitching	Enable		
ISBT 128			
ISBT 128 Concatenation	Disable		
Force Concatenation			
Concatenation Mode			
Dynamic Concat. Timeout			
Chain 0 - Chain 15			

Parameter	Default	Your Setting	Page
CODE SELECTION (continued)			
Interleaved 2 of 5 (I 2 of 5)			
I 2 of 5	Disable		
Standard 2 of 5			
Standard 2 of 5	Disable		
Codabar			
Codabar	Disable		
Code 11			
Code 11	Disable		
GS1 Databar Omnidirectional			
GS1 Databar Omnidirectional	Disable		
GS1 Databar Expanded			
GS1 Databar Expanded	Disable		
GS1 Databar Limited			
GS1 Databar Limited	Disable		
Code 93			
Code 93	Disable		
MSI			
MSI	Disable		

B KEYPAD

0



1



2



3



4



5



6



7



8



9



A



B



C



D



E



F



CANCEL



C ASCII/HEX/DECIMAL CHART

Char	Hex	Dec	Char	Hex	Dec	Char	Hex	Dec
NUL	00	0	*	2A	42	U	55	85
SOH	01	1	+	2B	43	V	56	86
STX	02	2	,	2C	44	W	57	87
ETX	03	3	-	2D	45	X	58	88
EOT	04	4	.	2E	46	Y	59	89
ENQ	05	5	/	2F	47	Z	5A	90
ACK	06	6	0	30	48	[5B	91
BEL	07	7	1	31	49	\	5C	92
BS	08	8	2	32	50]	5D	93
HT	09	9	3	33	51	^	5E	94
LF	0A	10	4	34	52	~	5F	95
VT	0B	11	5	35	53		60	96
FF	0C	12	6	36	54	a	61	97
CR	0D	13	7	37	55	b	62	98
SO	0E	14	8	38	56	c	63	99
SI	0F	15	9	39	57	d	64	100
DLE	10	16	:	3A	58	e	65	101
DC1	11	17	;	3B	59	f	66	102
DC2	12	18	<	3C	60	g	67	103
DC3	13	19	=	3D	61	h	68	104
DC4	14	20	>	3E	62	i	69	105
NAK	15	21	?	3F	63	j	6A	106
SYN	16	22	@	40	64	k	6B	107
ETB	17	23	A	41	65	l	6C	108
CAN	18	24	B	42	66	m	6D	109
EM	19	25	C	43	67	n	6E	110
SUB	1A	26	D	44	68	o	6F	111
ESC	1B	27	E	45	69	p	70	112
FS	1C	28	F	46	70	q	71	113
GS	1D	29	G	47	71	r	72	114
RS	1E	30	H	48	72	s	73	115
US	1F	31	I	49	73	t	74	116
SPACE	20	32	J	4A	74	u	75	117
!	21	33	K	4B	75	v	76	118
"	22	34	L	4C	76	w	77	119
#	23	35	M	4D	77	x	78	120
\$	24	36	N	4E	78	y	79	121
%	25	37	O	4F	79	z	7A	122
&	26	38	P	50	80	{	7B	123
'	27	39	Q	51	81		7C	124
(28	40	R	52	82	}	7D	125
)	29	41	S	53	83	~	7E	126
			T	54	84	DEL	7F	127

Char	Hex	Dec	Char	Hex	Dec	Char	Hex	Dec
	80	128		AA	170		D5	213
	81	129		AB	171		D6	214
	82	130		AC	172		D7	215
	83	131		AD	173		D8	216
	84	132		AE	174		D9	217
	85	133		AF	175		DA	218
	86	134		B0	176		DB	219
	87	135		B1	177		DC	220
	88	136		B2	178		DD	221
	89	137		B3	179		DE	222
	8A	138		B4	180		DF	223
	8B	139		B5	181		E0	224
	8C	140		B6	182		E1	225
	8D	141		B7	183		E2	226
	8E	142		B8	184		E3	227
	8F	143		B9	185		E4	228
	90	144		BA	186		E5	229
	91	145		BB	187		E6	230
	92	146		BC	188		E7	231
	93	147		BD	189		E8	232
	94	148		BE	190		E9	233
	95	149		BF	191		EA	234
	96	150		C0	192		EB	235
	97	151		C1	193		EC	236
	98	152		C2	194		ED	237
	99	153		C3	195		EE	238
	9A	154		C4	196		EF	239
	9B	155		C5	197		F0	240
	9C	156		C6	198		F1	241
	9D	157		C7	199		F2	242
	9E	158		C8	200		F3	243
	9F	159		C9	201		F4	244
	A0	160		CA	202		F5	245
	A1	161		CB	203		F6	246
	A2	162		CC	204		F7	247
	A3	163		CD	205		F8	248
	A4	164		CE	206		F9	249
	A5	165		CF	207		FA	250
	A6	166		D0	208		FB	251
	A7	167		D1	209		FC	252
	A8	168		D2	210		FD	253
	A9	169		D3	211		FE	254
				D4	212		FF	255

D RESERVED CHARACTERS

Reserved Characters	Hex Value	Notes
[SOH]	0x01	
[BEL]	0x07	
#	0x23	
\$	0x24	
0	0x30	
3	0x33	
B	0x42	
D	0x44	
E	0x45	
F	0x46	
R	0x52	
S	0x53	
h	0x68	
i	0x69	
s	0x73	
t	0x74	
[FF]	0xFF	
Reserved Strings		
C<up to 36 chars>[CR]	0x43 <xxx> 0x0D	C can be used without [CR] or inside a string (not the first character)
01[CR]	0x30 0x31 0x0D	
34[CR]	0x33 0x34 0x0D	

**Datalogic Automation S.r.l.**

Via Lavino 265

40050 Monte San Pietro

Bologna - Italy

www.automation.datalogic.com*declares that the***TC1200; Compact CCD Reader***and all its models**are in conformity with the requirements of the European Council Directives listed below:***2004 / 108 / EC EMC Directive***This Declaration is based upon compliance of the products to the following standards:***EN 55022 (CLASS A ITE), SEPTEMBER 1998:***INFORMATION TECHNOLOGY EQUIPMENT
RADIO DISTURBANCE CHARACTERISTICS
LIMITS AND METHODS OF MEASUREMENTS***EN 61000-6-2, SEPTEMBER 2005:***ELECTROMAGNETIC COMPATIBILITY (EMC)
PART 6-2: GENERIC STANDARDS - IMMUNITY FOR INDUSTRIAL
ENVIRONMENTS*

Monte San Pietro, July 20th, 2010

Lorenzo Girotti
Product & Process Quality Manager

